

1. Handset

1.1 TX

MIC signal output to U2 (DLH36000) via pin 42(MIC_N),pin43(MIC_P).when TX signal is received by U2, then processing via A/D, then output to RF by pin45(TXMOD).RF send TX to BASE.

1.2 RX

When RF receive the signal, after demodulation then send to baseband controller. baseband controller process the signal and transform to voice output to receiver(via pin 33 HS_out, pin 34 Lout0) or speaker(pin29 SPOUTP,pin31 SPOUTN)

Related component:

C24,SPK2,C55,C56,C57,SPK1,R70,EC9,R74

1.3 3.3V REGULATOR

3.3v regulator supply DC power for VCCR,VDD,VCCA,VCCRFPA. Related components:U7,Q11,R91,R92,D8,D9.

2. Base

2.1 TX

Telephone line signal output to U601(DHL36000) via pin 42 and pin 43.the signal processed by U601 then output to RF module via pin 57.

2.2 RX

RF received the signal, after demodulation then send to U601 via pin 66.U601 process the signal and transform to voice output to telephone line via pin34.

2.3 3.3V REGULATOR

Regulator U103 supply 3.3V power for base as well as VCCR and VCCA.

2.4 Ringer detection

Q101 detect the ringer signal and output the result to U601 pin 8.