

## **PMP3815 TEST MODE**

### **BASE**

- 1) Press and hold PAGE button while plugging-in battery pack, the unit will get into Test Mode and CH20 .
- 2) About P/T switch: being switched to P, then the RX is muted, if being switched to T, nothing is muted.
- 3) Upon detecting the state of charging, the unit transmits data, and simultaneously the TX is muted.
- 4) Press PAGE button, the channel can be changed.
- 5) While RSS2=1, the indicator of charging/in use goes out; anyway, if RSS2=0, then the indicator lights.

### **HANDSET**

- 1) Press and hold “\*” button while plugging-in the battery pack, the unit gets into Test Mode and CH20.
- 2) If you want to change the channel in natural sequence, just press “\*” button again and again. And if you want to change the channel in sequence of CH1, CH20, CH40, then you just need to press “0” button.
- 3) Press “#” button, the handset transmits code, simultaneously mute both TX and RX
- 4) RSS2=1, the new-call indicator goes out,  
RSS2=0, the new-call indicator lights