

Front Cover plus
Touch Panel Flex



Front Keymat



Front Cover Chin




Display Front




Display Back



AV Jack Back**AV Jack Front****Camera Module Back****Camera Module Front**


PWB Top Side



UI Flex and Chassis Back



UI Flex & Chassis Front





Back Cover

PWB Bottom

