MAIN

Brain Sensor

LEFT
RIGHT

AMP — Filter
AMP — Filter

MUX 4 kHz

Filter
Filter
Filter
Filter

Rx, TX Data
17 kHz

CPU
16 MHz

BUTTON

LCD
Lamp
Memory
Sound Filter 8 kHz
Sound Filter 8 kHz

AMP
AMP

SPEAKER