

Features

- Capacities : 16MB / 32MB / 64MB / 128MB / 256MB / 512MB / 1GB
- supports USB1.1
- 1 color illumination to indicate data transferring status(Green : data transferring)
- Power supply : USB powered(4.5V to 5.5V)
- Support OS : Windows98/SE,ME,2000,XP, Linux kernel2.4.0 or higher, Mac OS 8.6 or higher
- Dimension : 60 X 19 X 9mm
- Weight : 14g

DGlab co., Ltd

TEL : 82-502-878-5522



mini DRIVE
USB MEMORY DRIVE


User Manual

DGlab co., Ltd
TEL : 82-502-878-5522


User Manual

1. driver Installation for Windows 98/SE


- 1-1 Insert the supplied CD to "CD-ROM Drive" in PC, and plug the Mini Drive into PC's USB port.
The following dialog box "Add New Hardware Wizard" will show up onto your screen.
Then click "Next" button.



- 1-2 Check "Search for the best driver for your device" and click "Next" button




- 1-3 Check "CD-ROM drive" and click "Next" button.




User Manual


1-4 Dialog box shows that the driver locate in drive "D". and then click "Next" button.



1-5 The following dialog box shows that the driver installation has finished. Then click "Finish" button.




1-6 The following dialog box will show up onto your screen. Then click "Next" button.




1-7 Check the item and click "Next" button as same step as above 1-2,1-3.

1-8 Dialog box shows that the controller locate in drive "D". And then click "Next" button.




1-9 The following dialog box shows that the controller installation has finished. Then click "finish" button.



Now all driver and controller has been installed into your system.

2. how to use the Mini Drive

- When you insert the Mini Drive into PC's USB port, then the "Removable Disk" icon will appear in the "My Computer" folder.



- You can use the Mini Drive the same way as a Floppy disk or a Hard disk drive.
- When you pull out the Mini Drive from PC's USB port, then the "Removable Disk" icon will disappear in the "My Computer" folder.

3. how to format the Mini Drive

- select the "Removable Disk", and then click the Mouse's right button. The dialog box will show up, then press the "format" button and "start" button.

#Note

- When you remove the Mini Drive from the USB port, make sure that the green illumination on the USB storage Device is not flashing. This is to ensure that data will not be lost, even if the dialog box on your computer shows that the data transfer is finished.
- In Windows 2000, ME, and XP, the safe procedure will be to double click on the icon (🗑️) located at the bottom right corner of your screen and follow instructions before removing

◆ WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Errata Sheet for Mini Drive User Manual

No	Wrong	Correct
1-5	The following dialog box shows that the driver installation has <u>finihed</u> .	The following dialog box shows that the driver installation has <u>finished</u> .
1-9	The following dialog box shows that the <u>controlle</u> installation has finished.	The following dialog box shows that the <u>controller</u> installation has finished.
#Note	When you remove the Mini Drive from the USB port, make sure that the green illumination on the <u>USB storage Device</u> is not flashing.	When you remove the Mini Drive from the USB port, make sure that the green illumination on the <u>Mini Drive</u> is not flashing.