

## **RF-2080 working principle**

Since antenna received modulated signal, It transmits to Super-regeneration of incepted circuit to enlarge. Then LM358 calculated-enlarged circuit will make a demodulation management on it . Then sends to decoding, the control signal Control relay to put through or break boil. So control Output power source to turn on or turn off.