

LIST OF CHANNELS AND THEIR FREQUENCIES

Low Data Rate

CHANNEL	FREQUENCY
1	2.402568000 GHz
2	2.406348000 GHz
3	2.410128000 GHz
4	2.413908000 GHz
5	2.417688000 GHz
6	2.421468000 GHz
7	2.425248000 GHz
8	2.429028000 GHz
9	2.432808000 GHz
10	2.436588000 GHz
11	2.440368000 GHz
12	2.444148000 GHz
13	2.447928000 GHz
14	2.451708000 GHz
15	2.455488000 GHz
16	2.459268000 GHz
17	2.463048000 GHz
18	2.466828000 GHz
19	2.470608000 GHz
20	2.474388000 GHz
21	2.478168000 GHz

LIST OF CHANNELS AND THEIR FREQUENCIES

Medium Data Rate

CHANNEL	FREQUENCY
1	2.404836000 GHz
2	2.412396000 GHz
3	2.419956000 GHz
4	2.427516000 GHz
5	2.435076000 GHz
6	2.442636000 GHz
7	2.450196000 GHz
8	2.457756000 GHz
9	2.465316000 GHz
10	2.472876000 GHz

High Data Rate

CHANNEL	FREQUENCY
1	2.409372000 GHz
2	2.424492000 GHz
3	2.439612000 GHz
4	2.454732000 GHz
5	2.469852000 GHz