









SYNOS-SM-C200R-ES.sch-1 - Mon Nov 04 14:34:06 2002

The schematic diagram shows the FM TRANSMITTER section. It includes components such as C901, R902, C902, C903, DTCX4E, X901, L903, L904, C936, BPF301, C937, C938, C939, C940, C941, C942, C943, C944, C945, C946, C947, C948, C949, C950, C951, C952, C953, C954, C955, C956, C957, C958, C959, C960, C961, C962, C963, C964, C965, C966, C967, C968, C969, C970, C971, C972, C973, C974, C975, C976, C977, C978, C979, C980, C981, C982, C983, C984, C985, C986, C987, C988, C989, C990, C991, C992, C993, C994, C995, C996, C997, C998, C999, C1000. The diagram also shows various resistors (R901-R999) and capacitors (C901-C1000). The output is connected to an antenna (ANT) through a matching network.