

Side 1
115mm
Front Cover


480mm

Welcome

For a full instruction manual, please visit zagg.com/user-guides.
Mushroom is comprised of two pieces: a detachable keyboard and case.

Inserting Your Device into the Case:

Holding your device in landscape mode with the power control buttons facing up, press the top half of your device into the case and apply light pressure all around to snap it snugly into place.



Removing Your Device from the Case:

Hold on to the top lip of the case and press against the back of the case. Then, grasp the exposed side of your device and lift/pull it away from the cover.

Attaching/Detaching the Keyboard from the Case:


The top of the keyboard and the bottom of the case are magnetized and will snap securely together. They can be detached with a light pull.

The keyboard cradle is strong enough to be a stand for case and device.




Powering On/Off:

Slider power switch to "ON" side to turn your keyboard on. A red LED will light on for 3 seconds, then off. Slider power switch to "OFF" side to turn your keyboard off.




Pairing the Keyboard with Your Device:

Verify your device's Bluetooth® settings are on. Press "Fn" and "⌘" two keys together. A blue LED will flash until pairing is complete. Select "ZAGG Slim Book" from your device's list of available devices to complete pairing.



Charging Your Keyboard:

Plug the Type-C end of the charging cable into the Type-C port on the keyboard (right side). Plug the other end of your charging cable into your preferred USB charging outlet. A red LED light will illuminate to show that your keyboard is charging. When this light turns green, your keyboard is finished charging. Disconnect the charging cable.




Disconnecting Your Keyboard:

1. Turn off the Bluetooth connection from your device.
2. Turn the keyboard off.

Checking Your Battery Level:

To check your keyboard battery life, press fn + the battery key. The red LED light will flash one of the following four ways:

- 4 blue flashes = 76% or more battery life
- 3 blue flashes = 51-75% battery life
- 2 blue flashes = 25-50% battery life
- 1 blue flash = less than 25% battery life



Trouble Shooting

If your device doesn't respond to the keyboard, there may be a simple explanation. Try the following steps.

1. Restart your device.
2. Turn your keyboard off and back on.
3. Forget and re-pair your keyboard.
4. If, after charging, your keyboard doesn't operate correctly, please contact ZAGG Customer Service.

If you still experience problems, please contact ZAGG Customer Service.

zagg.com/support/contact.php | questions@zagg.com
1-800-700-ZAGG [9244]
00-1-801-839-3906 for international customers

⚠ WARNING

Keyboard use may be associated with physical injuries. If you experience any discomfort or pain, stop using your keyboard and consult a physician.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

©2024 ZAGG Inc. All Rights Reserved. ZAGG® and Pro Keys™ are trademarks of ZAGG Inc. iPad® is a trademark of Apple Inc., registered in the U.S. and other countries.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by ZAGG Inc is under license. Other trademarks and trade names are those of their respective owners.

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

96 mm