

User Mannual

1. Use only on 120V, 60Hz.
2. Never disassemble or modify---any changes could void the use's authority to operate this device.
3. Not for use in totally enclosed fixtures.
4. Risk of fire, do not install the lamp as following:
 - a. in luminaries fixtures controlled by a dimmer.
 - b. in emergency exit lamps used DC current.
 - c. in totally enclosed lamps and lanterns.
5. Use in dry condition, risk of electric shock---do not use where directly exposed to water.
6. This product could produce interference when used near a TV, radio, wireless remote control or maritime safety communications equipment or other critical navigation of communication equipment operating between 0.15-30MHz. If interference would occur, move the lamp away from the appliance a distance of three feet or more. Or plug the lamp or the appliance into a different outlet.
7. To prevent burns, do not touch the bulb during operating or immediately after switching off.
8. Not for use with dimmers, electronic timer or photocell devices or occupancy sensor.
9. It doesn't start up when placed below -18 .

FCC Note:

The manufacturer is not responsible for any radio or TV interference caused by unauthorized Modifications to this equipment. Such modification could void the user's authority to operation the equipment.

This product may cause interference to radio equipment and should not be installed near maritime safety communications equipment or other critical navigation or communication equipment operating Between 0.15-30MHz.