


3

Making the Remote Work With Your Receiver

1



Verify this key is installed, and continue with step 2.

2

Verify the remote antenna is installed on the back of the receiver.



3




Turn your ViP922 receiver and TV on, and select SYSTEM INFO on the receiver front panel.

4



Confirm that you see the System Information screen.

5



Press and release SAT on your remote. After a few seconds, you will hear a tone, and the remote will be listed on the screen.

6

Confirm that your remote operates your receiver by pressing remote buttons.

If this is not working, repeat step 5.

If the remote is still not linked to your ViP922 receiver, see page 10 in this guide.

