

Model : HS09 , Label Artwork and location sample



Dimension : 70 mm X 24 mm

KEEP AWAY FROM WATER DANGER

AS WITH MOST ELECTRICAL APPLIANCES, ELECTRICAL PARTS IN THIS STYLER ARE ELECTRICALLY LIVE EVEN WHEN THE SWITCH IS OFF. TO REDUCE RISK OF DEATH BY ELECTRIC SHOCK: ALWAYS "UNPLUG IT" AFTER USE. DO NOT PLACE OR STORE WHERE STYLER CAN FALL OR BE PULLED INTO TUB, TOILET, OR SINK. DO NOT USE WHILE BATHING. DO NOT USE NEAR OR PLACE IN WATER. IF STYLER FALLS INTO WATER, UNPLUG IMMEDIATELY. DO NOT REACH INTO WATER.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

JN.89399 PN.307847-02-02 17.04.18

WARNING CABLE LABEL