

# RemoteRemote Keyfob

## Setup/Operations Manual



### INTRODUCTION

The RemoteRemote keyfob is a simple 5 button RF wireless remote control.

### SETUP:

- Step 1: Carefully pop the case apart (use a small flat-blade screwdriver, or a thin piece of rigid plastic)
- Step 2: Remove the battery from the holder it came in. (Note the “+” symbol on the battery)
- Step 3: Insert the battery into the battery holder with the “+” symbol facing towards the metal battery bracket.
- Step 4: Carefully reinsert the board into the keyfob housing.
- Step 5: Snap the two keyfob halves back together. (it's a tight fit, so take your time)

### LEARNING:

The receiver was developed in such a way as to be able to learn new remotes (say if the original remote got lost and you bought a new one.) This process is relatively simple, but necessary before the receiver will recognize the remote. Once you have complete the setup steps above, you can proceed with the learning process. Note that some of these steps need to be done in a time-critical fashion, so you may want to read through the instructions first before attempting the procedure. Warning: Once a receiver has learned a keyfob transmitter, it CANNOT be unlearned!

- Step 1: At the same time, press and hold down the Volume Up and Volume Down buttons for 5 seconds (and then release)
- Step 2: Within an additional 5 seconds, press and release the Rewind, Fast Forward, and Play buttons (in that order)
- Step 3: Now press and hold the Play button for an additional 5 seconds (and then release)
- Step 4: Your receiver should now have learned your new remote.

### TROUBLESHOOTING

If there is no activity at the receiver you should try these troubleshooting tips:

- 1.) Make sure the receiver is on.
- 2.) Is the battery new? Does it need to be replaced?
- 3.) If you put in a new battery, was it inserted with the correct orientation (+ towards the metal bracket)
- 4.) Has the receiver learned the keyfob remote? If not, go through the LEARNING process.
- 5.) If these steps still don't help, please contact us.

### FCC STATEMENT

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not approved by the party responsible for FCC compliance could void the user's permission to operate this equipment.

### WARRANTY STATEMENT

Engineered Audio, LLC (EA) warrants to the original purchaser as follows: All EA products, under normal use, will be free from defects in material and workmanship for 12 months to the end user. EA will, at its sole option, repair or replace a product that is found to be defective. This warranty shall be invalid if, in the sole opinion of EA, a product failure is the result of misuse, abuse, or modification.

### RemoteRemote Keyfob TECHNICAL SPECIFICATIONS

- Dimensions: 2.2 x 1.4 x 0.5
- Built-in Antenna
- Power requirement: 3v lithium battery
- Modulation: AM/OOK
- Frequency: 315Mhz
- Operating range: ~100 feet (limited by FCC regulations)
- FCC compliant (FCC QWB-REM1001)