


# Smart Talking Truck

## User manual for the parents

Ref: 8226



### How to play :

- (1) Remove the "Pull Tag" from the chassis.
- (2) Cut away the yellow string which is attached with the green car.
- (3) Press : Truck engine sound.
- (4) Press : Learn how to count number of cars.
- (5) Press : Listen to the four different car sounds.
- (6) Press : Learn how to study the four different colors of the cars.
- (7) Press : for Quiz mode. Follow the instruction to park the car on the parking ramp.

**"Note: To ensure the truck correctly identifies the cars place each car one at a time and make sure the first car on the top/ bottom bays are pushed to the end"**

### Remarks:

The proper functions will perform well and accurately under the following conditions:

- (a) When removing a car from the truck, wait until the sentence is spoken before replacing it to obtain the next sentence.
- (b) The car should be placed correctly on their slots
- (c) If the truck stops recognizing the cars or recognizes incorrectly, please replace the batteries.


### Instructions :

- Batteries should be installed and changed by an adult.
- Open the battery compartment with a screw-driver
- Make sure the batteries are installed in the right direction according to the diagram. A wrong position can damage the toy, provoke fire or the batteries explosion.
- Close the lid of the battery compartment
- Do not mix old and new batteries.
- Do not store batteries with metal objects: fire or explosion hazard.
- Remove batteries when the toy is not used for a long period of time.
- Do not throw batteries in a fire.
- Do not attempt to recharge batteries which are not rechargeable.
- Do not attempt to open batteries or rechargeable batteries.
- In case a battery is swallowed consult immediately the doctor or a poison center.
- If available get rid of your used batteries through a collection center.
- Use preferably alkaline batteries.
- Never let button-cell batteries in reach of young children.
- Rechargeable batteries are only to be charged under adult supervision.
- Rechargeable batteries are to be removed from the toy before being charged.
- Exhausted batteries are to be removed from the toy.
- The supply terminals are not to be short-circuited.
- Different types of batteries or new and used batteries are not mixed.
- Do not mix alkaline, standard (carbon-zinc), or re-chargeable (nickel-cadmium) batteries.
- In case of malfunction, open the battery compartment, remove the batteries, re-install them and close the battery compartment.

**English** Processing of electric and electronic equipment at the end of their service life (applicable in member countries of the European Union and other European countries operating a selective waste collection system). This symbol, affixed to the product or its packaging, indicates that the product must not be processed with household waste. It must be brought to an electric and electronic waste collection point for recycling and disposal. By ensuring the appropriate disposal of this product you also help in preventing potentially negative consequences for the environment and human health. The recycling of materials helps preserve our natural resources. For further information regarding the recycling of this product, please contact your municipality, local waste disposal centre or the store where the product was purchased.

During the replacement of your used batteries, we request that you follow the current regulations as to their elimination. We thank you for depositing them in a location foreseen for that purpose to ensure their elimination in a sure manner and with respect for the environment.

### Battery Installation :



- (1) Use a cross shape screwdriver to remove the screw attaching the battery lid.
- (2) Slide the lid to the side and remove.
- (3) Install 4 "AA" size 1.5V batteries. Make sure that the + and - poles are positioned properly.
- (4) Replace the battery compartment lid and screw in.



**Room 603 – 609, 6th floor, West Wing Office Building,  
New World Centre, 20 Salisbury Road,  
Tsim Sha Tsui, Kowloon, Hong Kong  
Tel : (852) 3756 0300 Fax : (852) 3756 0301  
e-mail : info@bao-toys.com.hk**

**FCC ID: QWS8226V User Manual**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.