



COMFORTABLE ELECTRONIC CO., LTD.

EXPORTERS, IMPORTERS & MANUFACTURERS



3 FL., NO. 142, LI-TEH STREET
CHUNG HO CITY TAIPEI HSIEN
TAIWAN, R. O. C.

TEL : 886-2-32347735 (REP.)
FAX : 886-2-32347739, 32348039
E-MAIL : comf@tpts1.seed.net.tw

[Http://www.asiansources.com/comf.co](http://www.asiansources.com/comf.co)

[Http://www.comf.com.tw](http://www.comf.com.tw)

OPERATING MANUAL

CAR PET

Wireless Handsfree Car Kit-by Car Radio System

Instruction

1. How to install

- a. Clip the unit onto the speaker part of your phone set.
- b. Place the phone set on the Phone Holder (option) or other convenient place in your car-Important(Keep within 1 meter between the driver and this unit, as the speaker party is talking from the Internal Mic of the phone set.

2. How to use

- a. Turn the Car Radio to the right station (Frequency as shown on this packing).
- b. Switch on the power and the LED will be on.
- c. Switch off the power after conversation to avoid the battery being driven off (Important)
- d. Please slightly tune the frequency of the radio station if any slight cacophony is heard.

3. Trouble shooting

- a. Decrease the volume of your Car Radio or your phone set to avoid heavy Echo.
- b. Replace the internal battery in case of heavy cacophony or a shorter distance reception.

4. How to replace the battery (2032 Li-on standard cell*1)

- a. Push the clip at bottom to open the battery cover.
- b. Put the cell into the battery case.
- c. Rebound the battery cover.

5. Main feature

- a. Talking time (continuous) to 10 hours (approx)
- b. Standby time to 30 days (approx)
- c. Available distance for transmission around 3 meters.
- d. Beaming power< 5dBm.
- e. 1PC 2032 standard cells.

Notice : The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATIONS IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRED OPERATION.