



Photographs of the Test Configuration


Conducted Emission Test (PIFA antenna, Adapter mode)




Conducted Emission Test (PIFA antenna, POE mode)




Conducted Emission Test (Dipole antenna, Adapter mode)




Conducted Emission Test (Dipole antenna, POE mode)




Conducted Emission Test (Directional Panel antenna (model WS-AI-DQ04360), Adapter mode)





Conducted Emission Test (Directional Panel antenna (model WS-AI-DQ04360), POE mode)



Conducted Emission Test (Directional Panel antenna (model WS-AI-DD05120), Adapter mode)




Conducted Emission Test (Directional Panel antenna (model WS-AI-DD05120), POE mode)





For 2.4G



Radiated Emission Test (PIFA antenna, Adapter mode)





Radiated Emission Test (PIFA antenna, POE mode)





Radiated Emission Test (Dipole antenna, Adapter mode)





Radiated Emission Test (Dipole antenna, POE mode)





Radiated Emission Test (Directional Panel antenna (model WS-AI-DQ04360), Adapter mode)





Radiated Emission Test (Directional Panel antenna (model WS-AI-DQ04360), POE mode)



Radiated Emission Test (Directional Panel antenna (model WS-AI-DD05120), Adapter mode)





Radiated Emission Test (Directional Panel antenna (model WS-AI-DD05120), POE mode)





For 5G



Radiated Emission Test (PIFA antenna, Adapter mode)




Radiated Emission Test (PIFA antenna, POE mode)




Radiated Emission Test (Dipole antenna, Adapter mode)





Radiated Emission Test (Dipole antenna, POE mode)





Radiated Emission Test (Directional Panel antenna (model WS-AI-DQ04360), Adapter mode)



Radiated Emission Test (Directional Panel antenna (model WS-AI-DQ04360), POE mode)



Radiated Emission Test (Directional Panel antenna (model WS-AI-DD05120), Adapter mode)



Radiated Emission Test (Directional Panel antenna (model WS-AI-DD05120), POE mode)

