


1. Photographs of Radiated Emissions Test Configuration

Test Mode: Mode 1 and Mode 2

FRONT VIEW




REAR VIEW



Test Mode: Mode 3

FRONT VIEW



REAR VIEW



—————THE END—————