

EXTERNAL PHOTOS OF TESTED EUT


1.1 HCR 800/805 with HCC 100 PHOTOS



General view, HCR 800/805 reader with HCC 100 docking station (with USB cable)



Rear view, HCR 800/805 reader with HCC 100 docking station (with USB cable)



Right view, HCR 800/805 reader with HCC 100 docking station (with USB cable)


1.2 HCR 800/805 PHOTOS



Front view of HCR 800/805 reader



Bottom view of HCR 800/805 reader (interface connector)



Top view of HCR 800/805 reader (antenna side)



Right view of HCR 800/805 reader



Left view of HCR 800/805 reader




Rear side of HCR 800/805 reader

1.3 HCC 100 PHOTOS



General view of HCC 100 docking station



Rear view of HCC 100 docking station



Top view of HCC 100 docking station



Under view of HCC 100 docking station