


1. External Photograph of the Host

Host: Tablet PC

(Brand Name: Getac / Model Name: F110, F110G7, F110-701, F110-711, F110-721, F110-Exc, F110Y (Y= 10 characters, Y can be 0-9, a-z, A-Z, "-", "_" or blank for marketing purpose and no impact safety related critical components and constructions.))


SKU A















SKU B
















SKU C


















2. Photograph of Accessory for the Host

List of Accessory for Host (Tablet PC):

Specification of Accessory		
AC Adapter 1	Brand Name	Getac
	Model Name	MTA190474W4
AC Adapter 2	Brand Name	FSP GROUP INC.
	Model Name	FSP090-ABBN3
AC Adapter 3	Brand Name	FSP GROUP INC.
	Model Name	FSP065-RBBN3
Battery 1	Brand Name	Getac
	Model Name	BP3S2P2100S-02
Battery 2	Brand Name	Getac
	Model Name	BP3S1P2680B
Touch Pen	Brand Name	Getac
	Model Name	GT-090S

Remark: For accessories equipped with this EUT, please refer to the following photos.



AC Adapter 1



AC Adapter 2



AC Adapter 3



Battery 1



Battery 2

