

SAR Test Setup Photographs

EUT Side Definition		
Mode	Side	
1	Back	
2	Side 1	
3	Side 2	
		

Phantom Position : Flat	EUT side : Back
Spacing to phantom : 0 mm	Accessory : N/A



Phantom Position : Flat	EUT side : Back
Spacing to phantom : 7 mm	Accessory : N/A




Phantom Position : Flat	EUT side : Back (Battery 2)
Spacing to phantom : 0 mm	Accessory : N/A



Phantom Position : Flat	EUT side : Side 1
Spacing to phantom : 0 mm	Accessory : N/A



Phantom Position : Flat	EUT side : Side 1
Spacing to phantom : 10 mm	Accessory : N/A
	
Phantom Position : Flat	EUT side : Side 1 (Battery 2)
Spacing to phantom : 0 mm	Accessory : N/A
	

Phantom Position : Flat	EUT side : Side 2
Spacing to phantom : 0 mm	Accessory : N/A
	