

FUNCTIONAL BLOCK DIAGRAM

SUNTREE HOLDINGS CO., LTD.
Document release under NDA, All rights reserved.

SLAVE TRANSMIT SENSOR UNIT

STRFS2L-K03.pcb
RESET PCB

MASTER RESET,
TOGGLE TEMP.
FROM UNIT C TO F.

STRFS2L-R05.pcb
SENSOR PCB
-HUMIDITY SENSING
-TEMPERATURE SEN.

STRFS2T03.pcb
RF transmitting PCB
433.92 MHz
Sending ASK signal to
Mater periodically

STRFS2L-M07.pcb
MAIN BOARD

MCU FUNCTIONS:
-TAKE VALUE FROM
SENSOR BRD,
SENDING TO RF TO
TRANSMIT.