


OPERATIONS MANUAL

Long Range Walkie Talkie



Owners Manual
and Instructions

FCC WARNINGS

INFORMATION TO USER

The user that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC INFORMATION

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and if not installed and use in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.



Operation is subject to the following two conditions:

- (1) this device may not cause interference, and
- (2) this device must accept any interference, including interference that may cause undesired operation of the device.


OPERATION INSTRUCTIONS

1. Inserting the battery: Open battery compartment on the side of figure with screwdriver. Lift off the door. Using the battery connector inside the compartment, snap in a 9-volt battery.
2. To turn the walkie talkie on: Move the Vol. switch located on the bottom of the unit to ON position then LED will turn ON. Adjust the Vol. Switch till you hear a low hissing background noise which indicates the unit is working properly.
3. To transmit to another relative walkie talkie: Repeat the same act as above. Put it on your head when you speak to.
4. To turn the walkie talkie off: Move the Vol. switch the Off position then LED will turn OFF. This maintains the battery life.
5. To turn the flash light on, rotate the flash light head clock wise
To turn the flash light OFF, rotate the flash light head counter clock wise until light off.

BATTERY COMPARTMENT



FLASHLIGHT



ON/OFF

Battery Use Instructions

Non-rechargeable batteries are not to be recharged.
Exhausted batteries are to be removed from the toy.
The supply terminals are not to be short-circuited.

Do not mix old and new batteries.

Do not mix alkaline, standard (Carbon Zinc) or rechargeable (Nickel Cadmium) batteries

Only batteries of the same or equivalent type as recommended are to be used.

Batteries are to be inserted with the correct polarity.