



Download from www.evoluent.com
Copyright 2019 Evoluent. Patented.

Moving Mouse Without Moving Pointer

Tilt it to disable tracking. Slide it to a new position.

Windows

1. Before connecting VeriMouse/Logi, go to Control Panel to open Mouse properties.

2. In the Buttons tab, uncheck Switch Primary and Secondary Buttons

3. In the Buttons tab, click the Double-Click Enable/Disable Pointer Precision and set the pointer speed slider to the middle position.

4. Connect VeriMouse/Logi by inserting the charge plug or receiver in a USB port. If your mouse is not connected, the mouse will not work.

5. Press the pointer speed button on the side of the mouse to activate three lights. The VM model has a speed button on the bottom. These are the default button functions when the Evolver driver is not installed.

	VMC	VMD	VM3	VB3
Left thumb	left click	left click	left click	left click
Right thumb	middle click	middle click	middle click	middle click
Wheel	forward	forward	forward	middle click
Thumb	backward	backward	backward	middle click
Top thumb	right click	right click	right click	forward
Bottom thumb	black	black	black	backward
Bottom thumb	needs driver	needs driver	needs driver	needs driver

6. Download the Evolver Mouse Manager software. It is available and installed for customizing buttons and useful ergonomic functions. Download the driver from www.evolver.com

Tip: Button functions can be customized by installing Evolver Mouse Manager

1. **Connecting VerticalMouse:**
 1. **Wired models:**
Connect the cable to a USB port.
 2. **Wireless models with receiver:**
Connect the receiver to a USB port. Insert the battery and slide the power switch to the green position.
 3. **Mac/iOS Bluetooth models without receiver:**
Go to the System Preferences and click Setup New Device or click + to add the device. Insert the battery and slide the power switch to the green position or turn it off and on to begin pairing.
2. **Adjusting scroll speed** (on the side of the mouse) to activate three lights.
3. **Evolution Mouse Manager (a driver)** may optionally be installed for customizing the buttons. Download the driver from www.evolutem.com. You may have to temporarily allow the program to download from anywhere in System Preferences, Security and Privacy.

Window

Window

Installa

Windows

Window

[illegible]

Window

We want to make sure you are happy with your Evoluent!
If you have any questions or problems with the VerticalMouse, please contact us
E-mail: help@evoluent.com
Phone: +1 650 871 1365
Monday to Friday, 9 am to 5 pm, USA Pacific time.

FCC Compliance Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. This equipment complies with the FCC's radio frequency interference requirements by complying with one or more of the following conditions: (1) This device meets the requirements of part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used properly, it may cause interference to radio communications. However, there is no guarantee that interference will not occur under all conditions. (2) Changes to or modifications of this device's instructions must be approved by the manufacturer to maintain compliance with FCC interference requirements. Such changes or modifications may be made by the user, provided that the user is notified by the manufacturer of the need to make such changes or modifications. (3) The user must follow the following steps to correct or eliminate the interference: 1) Turn the equipment off and on, the user is advised to turn the equipment off for at least 15 seconds. 2) Change the location of the equipment or relocate the receiving antenna. 3) Increase the separation between the equipment and receiver. 4) Plug the power cord into a different wall outlet. 5) Have the equipment inspected and connected. 4) Consult the dealer or an experienced radio/television technician for help. 5) If the interference persists, contact the manufacturer for more information. The user is not authorized to grant the user by the FCC to operate this equipment. This device has been evaluated to meet general product exposure requirements. This device may be used in portable electronic applications without restriction.

ion, Science and Economic Development Canada license-exempt

2) (this device must accept any interference, including interference that may cause undesired operation of the device.)
This device has been evaluated to meet general RF exposure requirements. This device may be used in portable exposure conditions without restriction.
Ce dispositif est conforme aux normes et aux exigences de licence d'innovation, sciences et développement économique Canada. L'exploitateur n'est autorisé que dans des conditions suivantes:

- 1) l'appareil ne doit pas produire de brouillage, et
- 2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'entraver une partie de son fonctionnement.

Le matériel a été évalué pour répondre aux exigences générales d'exposition aux radiofréquences.