

D700-2017

Bluetooth® Sports Headset

USER MANUAL



Security Precautions


In order to have a proper and safety use of the headset, please read this user manual in detail and save it.

■ Be sure to aware the following guidelines when using your headset:

1. Should adjust volume and time reasonably when using the headset.
2. Please stop using the headset in potentially hazardous situation to ensure your safety.
3. Please avoid using headset to listen to music, make or receive calls to avoid distraction while driving.
4. Put this product and its accessories somewhere out of the reach of children, to avoid a fatal danger caused by inappropriate use.
5. Should keep water from entering the headset during grooming, which may cause damage to the sound quality or the headset.
6. Should avoid turning the volume so high that you can't hear anything around you. If you feel a tinnitus or the volume is too high, please reduce the volume.
7. Stop using the headset if you feel obvious discomfort, irritation or have other adverse reactions.
8. The headset should not be stored or used at temperatures below 15°C (5°F) or above 55°C (131°F) which may shorten headset or battery life.

Overview of Headset

Overview of D700 Bluetooth stereo headset:



Bluetooth sports headset in the box

- Bluetooth sports headset 1pcs
- User's manual 1pcs
- USB charging cable 1pcs

Charger and battery

1. Before charging, make sure the headset has been switched off.
2. Plug USB cable into the charging port of headset; plug the other side of USB cable into the USB charger or other charging device. Charging will start and the red light remains bright on the headset.
3. Charging time of headset takes approximately up to 1.5-2hours, red light switch off after charging completed.

Overview of Headset

Warning: Must use original cable to charge for the Bluetooth headset, otherwise it may damage the headset. Thus, voltage of charger must be 5V, electric current exceed 100mA(5V/100mA).

This headset uses a non-detachable built-in rechargeable battery, in order to prevent damage of the headset, please do not remove the battery.

■ Power on:

- Keep pressing the MF button until blue lights blink, headset issue a voice.

■ Pairing Mode:

- Keep pressing the MF button until blue and red lights blink alternatively, headset issue a voice.

■ Switch off:

- Keep pressing the MF button until red lights blinks and goes out, headset issue a voice.

■ Pair your headset with your mobile phone :

1. Keep the distance between the headset and mobile phone (or other devices need to be connected) within 1 meter. The closer, the better.
2. Keep pressing the MF button until blue and red lights blink alternatively, enter to pairing mode.
3. Initiate Bluetooth function of mobile phone (or other device need to be connected). Then "SYLLABLE D700" will be shown on your phone.
4. Select "SYLLABLE D700" (some mobile phones need you to input PIN "0000" as password) and the headset will automatically connect with your mobile phone, the blue lights begin to blink. Attention: Generally, there are 120 seconds at maximum to pair headset with your mobile phone, or the Bluetooth pairing mode will stop when the lights goes out. Please retry steps 1 to 4 to pair again if your operation doesn't work.

Overview of Headset

■ Disconnect the headset with your mobile phone:

- Close the Bluetooth function of your mobile phone.
- Or keep press the MF button until the red lights goes out, to switch off the headset.
- Or take the headset from the mobile phone to more than 20m (60ft) away.

■ Reconnect the paired headset with your mobile phone:

1. Keep distance of the headset and mobile phone (or other devices need to be connected) within 1 meter, the closer, the better .
2. Switch on the headset, and the headset enters into reconnection mode when the blue light blinks.
3. Switch on the Bluetooth search function in your mobile phone or other devices need to be connected. Then the headset will automatically reconnect with the mobile phone which has connected last time.

■ Answer incoming call:

- When there is an incoming call, the headset will issue the a voice message , press the MF button once to answer the call, or use your mobile phone to answer it.

■ Reject a call:

- When there is an incoming call, the headset will issue a voice message, keep pressing the MF button for 2 times to reject the call, or use your mobile phone to reject the call .

■ Hang up a call:

- Press the MF button once or use your mobile to hang up your call.

FAQ

■ Last call redialing:

- In standby mode, double-click the MF button, can redial your last call.

■ Music Play/Pause:

- Press MF button once to play/pause music.

■ Volume adjustment/Music selection:

- Press Vol(+) and Vol(-) once to adjust volume; keep presses the Vol(+) and Vol(-) to select previous track or next track.

FAQ

1. Headset cannot pair with mobile phone?

Ans: Please check whether your headset is in pairing mode or reconnection mode, check whether Bluetooth search function of your mobile phone has been opened. Thus, check your mobile device's Bluetooth menu and delete/forget the headset, reconnect the headset following instructions of user manual.

2. Headset cannot be switch on?

Ans: Please check the battery status of your headset.

3. Can I change battery for the headset?

Ans: No, this headset use a built-in non-detachable Li-Polymer battery, it can not be removed.

4. Can I use headset while driving?

Ans: For safety reason, we strongly recommend not to use over-ear headset to avoid distraction while driving.

5. Headset disconnect with your mobile phone within 10 meter?

Ans: Please check if there is metal or other material within relatively close range may interfere Bluetooth connection, as Bluetooth is a radio technology that is sensitive to objects between the headset and the connected device.

6. Cannot hearing a sound from your computer or mobile phone?

Ans: Please check whether the output channel of your computer is Bluetooth Audio Device and Bluetooth function of your computer support A2DP profile. And please check volume of your headset/computer/mobile phone.

7. Cannot use the headset to control volume or select track of APP of your mobile phone?

Ans: Software settings of APP may be varied led to some functions of the APP may not control by the headset.

Specification

■ Specification:

- Bluetooth version: V4.1
- Impedence: 32 OHM
- Frequency range: 2.4GHz – 2.48GHz
- Operating distance: up to 10m (free space)
- Standby time: up to 180hrs
- Talking/music-playing time: about 4~5 hours
- Charging time: about 0.5 hours
- Bluetooth profiles: A2DP, AVRCP, HSP, HFP
- Frequency response: 20 -22kHz
- Operating Temperature:-10°~50°C
- Cable length: 70CM



Shenzhen Kaijuyuan Technology Co., Ltd.

Pretty Rhythm Co., Ltd.

Address : Taizhixing 403-406 Building 8, Minfu RD, Minzhi Street, Longhua District, Shenzhen City, Guangdong Province, China

Fax : +86 755 23208316

Tel : +86 755 83828491 23208363

Aftersales Service Hotline : 4006553968

Website : www.syllable-syllable.com

E-mail of aftersales service : syllableservice@syllable-syllable.com

Technical , specifications are subject to change
without notice ,we apologize for any inconvenience.

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.