




1-N78-3700-3800-PC2-30-50-M-3-DFT-16QAM-Outer_Full-128@0-Ant7-45.734-48.70-≤50-PASS



1-N78-3700-3800-PC2-30-50-M-4-DFT-64QAM-Outer_Full-128@0-Ant7-45.819-48.64-≤50-PASS




1-N78-3700-3800-PC2-30-50-M-5-DFT-256QAM-Outer_Full-128@0-Ant7-45.728-48.81-≤50-PASS



1-N78-3700-3800-PC2-30-50-M-6-CP-QPSK-Outer_Full-133@0-Ant7-47.577-50.47-≤50-PASS



1-N78-3700-3800-PC2-30-50-M-7-CP-16QAM-Outer_Full-133@0-Ant7-47.597-50.45-≤50-PASS



1-N78-3700-3800-PC2-30-50-M-8-CP-64QAM-Outer_Full-133@0-Ant7-47.543-50.38-≤50-PASS



1-N78-3700-3800-PC2-30-50-M-9-CP-256QAM-Outer_Full-133@0-Ant7-47.651-50.60-≤50-PASS




1-N78-3700-3800-PC2-30-50-H-1-DFT-QPSK-Outer_Full-128@0-Ant7-45.916-48.73-≤50-PASS



1-N78-3700-3800-PC2-30-50-H-3-DFT-16QAM-Outer_Full-128@0-Ant7-45.771-48.50-≤50-PASS



1-N78-3700-3800-PC2-30-50-H-4-DFT-64QAM-Outer_Full-128@0-Ant7-45.820-48.70-≤50-PASS



1-N78-3700-3800-PC2-30-50-H-5-DFT-256QAM-Outer_Full-128@0-Ant7-45.745-48.62-≤50-PASS



1-N78-3700-3800-PC2-30-50-H-6-CP-QPSK-Outer_Full-133@0-Ant7-47.546-50.54-≤50-PASS



1-N78-3700-3800-PC2-30-50-H-7-CP-16QAM-Outer_Full-133@0-Ant7-47.629-50.57-≤50-PASS



1-N78-3700-3800-PC2-30-50-H-8-CP-64QAM-Outer_Full-133@0-Ant7-47.557-50.37-≤50-PASS



1-N78-3700-3800-PC2-30-50-H-9-CP-256QAM-Outer_Full-133@0-Ant7-47.651-50.37-≤50-PASS



1-N78-3700-3800-PC2-30-60-L-1-DFT-QPSK-Outer_Full-162@0-Ant7-57.991-61.41-≤60-PASS



1-N78-3700-3800-PC2-30-60-L-3-DFT-16QAM-Outer_Full-162@0-Ant7-57.935-61.46-≤60-PASS



1-N78-3700-3800-PC2-30-60-L-4-DFT-64QAM-Outer_Full-162@0-Ant7-57.893-61.25-≤60-PASS



1-N78-3700-3800-PC2-30-60-L-5-DFT-256QAM-Outer_Full-162@0-Ant7-57.936-61.23-≤60-PASS



1-N78-3700-3800-PC2-30-60-L-6-CP-QPSK-Outer_Full-162@0-Ant7-57.837-61.09-≤60-PASS



1-N78-3700-3800-PC2-30-60-L-7-CP-16QAM-Outer_Full-162@0-Ant7-57.876-61.68-≤60-PASS



1-N78-3700-3800-PC2-30-60-L-8-CP-64QAM-Outer_Full-162@0-Ant7-57.760-61.43-≤60-PASS



1-N78-3700-3800-PC2-30-60-L-9-CP-256QAM-Outer_Full-162@0-Ant7-58.048-61.36-≤60-PASS



1-N78-3700-3800-PC2-30-60-M-1-DFT-QPSK-Outer_Full-162@0-Ant7-57.958-61.37-≤60-PASS



1-N78-3700-3800-PC2-30-60-M-3-DFT-16QAM-Outer_Full-162@0-Ant7-57.919-61.41-≤60-PASS



1-N78-3700-3800-PC2-30-60-M-4-DFT-64QAM-Outer_Full-162@0-Ant7-57.857-61.34-≤60-PASS



1-N78-3700-3800-PC2-30-60-M-5-DFT-256QAM-Outer_Full-162@0-Ant7-57.840-61.16-≤60-PASS



1-N78-3700-3800-PC2-30-60-M-6-CP-QPSK-Outer_Full-162@0-Ant7-57.797-61.23-≤60-PASS



1-N78-3700-3800-PC2-30-60-M-7-CP-16QAM-Outer_Full-162@0-Ant7-57.815-61.41-≤60-PASS



1-N78-3700-3800-PC2-30-60-M-8-CP-64QAM-Outer_Full-162@0-Ant7-57.705-61.34-≤60-PASS



1-N78-3700-3800-PC2-30-60-M-9-CP-256QAM-Outer_Full-162@0-Ant7-57.972-61.28-≤60-PASS



1-N78-3700-3800-PC2-30-60-H-1-DFT-QPSK-Outer_Full-162@0-Ant7-58.008-61.40-≤60-PASS



1-N78-3700-3800-PC2-30-60-H-3-DFT-16QAM-Outer_Full-162@0-Ant7-57.955-61.43-≤60-PASS



1-N78-3700-3800-PC2-30-60-H-4-DFT-64QAM-Outer_Full-162@0-Ant7-57.889-61.39-≤60-PASS



1-N78-3700-3800-PC2-30-60-H-5-DFT-256QAM-Outer_Full-162@0-Ant7-57.869-61.26-≤60-PASS



1-N78-3700-3800-PC2-30-60-H-6-CP-QPSK-Outer_Full-162@0-Ant7-57.844-61.39-≤60-PASS




1-N78-3700-3800-PC2-30-60-H-7-CP-16QAM-Outer_Full-162@0-Ant7-57.827-61.16-≤60-PASS



1-N78-3700-3800-PC2-30-60-H-8-CP-64QAM-Outer_Full-162@0-Ant7-57.784-61.26-≤60-PASS



1-N78-3700-3800-PC2-30-60-H-9-CP-256QAM-Outer_Full-162@0-Ant7-58.027-61.33-≤60-PASS



1-N78-3700-3800-PC2-30-70-L-1-DFT-QPSK-Outer_Full-180@0-Ant7-64.666-68.30-≤70-PASS



1-N78-3700-3800-PC2-30-70-L-3-DFT-16QAM-Outer_Full-180@0-Ant7-64.384-68.44-≤70-PASS



1-N78-3700-3800-PC2-30-70-L-4-DFT-64QAM-Outer_Full-180@0-Ant7-64.406-68.35-≤70-PASS



1-N78-3700-3800-PC2-30-70-L-5-DFT-256QAM-Outer_Full-180@0-Ant7-64.448-68.03-≤70-PASS



1-N78-3700-3800-PC2-30-70-L-6-CP-QPSK-Outer_Full-189@0-Ant7-67.744-71.61-≤70-PASS



1-N78-3700-3800-PC2-30-70-L-7-CP-16QAM-Outer_Full-189@0-Ant7-67.673-71.59-≤70-PASS




1-N78-3700-3800-PC2-30-70-L-8-CP-64QAM-Outer_Full-189@0-Ant7-67.734-71.69-≤70-PASS



1-N78-3700-3800-PC2-30-70-L-9-CP-256QAM-Outer_Full-189@0-Ant7-67.588-71.78-≤70-PASS



1-N78-3700-3800-PC2-30-70-M-1-DFT-QPSK-Outer_Full-180@0-Ant7-64.589-68.26-≤70-PASS



1-N78-3700-3800-PC2-30-70-M-3-DFT-16QAM-Outer_Full-180@0-Ant7-64.308-68.24-≤70-PASS



1-N78-3700-3800-PC2-30-70-M-4-DFT-64QAM-Outer_Full-180@0-Ant7-64.366-68.24-≤70-PASS




1-N78-3700-3800-PC2-30-70-M-5-DFT-256QAM-Outer_Full-180@0-Ant7-64.357-68.00-≤70-PASS



1-N78-3700-3800-PC2-30-70-M-6-CP-QPSK-Outer_Full-189@0-Ant7-67.652-71.45-≤70-PASS




1-N78-3700-3800-PC2-30-70-M-7-CP-16QAM-Outer_Full-189@0-Ant7-67.590-71.43-≤70-PASS




1-N78-3700-3800-PC2-30-70-M-8-CP-64QAM-Outer_Full-189@0-Ant7-67.629-71.59-≤70-PASS



1-N78-3700-3800-PC2-30-70-M-9-CP-256QAM-Outer_Full-189@0-Ant7-67.477-71.61-≤70-PASS




1-N78-3700-3800-PC2-30-70-H-1-DFT-QPSK-Outer_Full-180@0-Ant7-64.670-68.20-≤70-PASS



1-N78-3700-3800-PC2-30-70-H-3-DFT-16QAM-Outer_Full-180@0-Ant7-64.343-68.17-≤70-PASS



1-N78-3700-3800-PC2-30-70-H-4-DFT-64QAM-Outer_Full-180@0-Ant7-64.380-68.22-≤70-PASS




1-N78-3700-3800-PC2-30-70-H-5-DFT-256QAM-Outer_Full-180@0-Ant7-64.404-68.15-≤70-PASS



1-N78-3700-3800-PC2-30-70-H-6-CP-QPSK-Outer_Full-189@0-Ant7-67.722-72.38-≤70-PASS




1-N78-3700-3800-PC2-30-70-H-7-CP-16QAM-Outer_Full-189@0-Ant7-67.704-71.62-≤70-PASS




1-N78-3700-3800-PC2-30-70-H-8-CP-64QAM-Outer_Full-189@0-Ant7-67.645-71.51-≤70-PASS



1-N78-3700-3800-PC2-30-70-H-9-CP-256QAM-Outer_Full-189@0-Ant7-67.564-71.58-≤70-PASS



1-N78-3700-3800-PC2-30-80-L-1-DFT-QPSK-Outer_Full-216@0-Ant7-77.419-81.23-≤80-PASS



1-N78-3700-3800-PC2-30-80-L-3-DFT-16QAM-Outer_Full-216@0-Ant7-76.985-81.28-≤80-PASS



1-N78-3700-3800-PC2-30-80-L-4-DFT-64QAM-Outer_Full-216@0-Ant7-77.258-81.60-≤80-PASS




1-N78-3700-3800-PC2-30-80-L-5-DFT-256QAM-Outer_Full-216@0-Ant7-77.136-81.25-≤80-PASS




1-N78-3700-3800-PC2-30-80-L-6-CP-QPSK-Outer_Full-217@0-Ant7-77.554-81.82-≤80-PASS



1-N78-3700-3800-PC2-30-80-L-7-CP-16QAM-Outer_Full-217@0-Ant7-77.553-81.59-≤80-PASS



1-N78-3700-3800-PC2-30-80-L-8-CP-64QAM-Outer_Full-217@0-Ant7-77.702-81.77-≤80-PASS




1-N78-3700-3800-PC2-30-80-L-9-CP-256QAM-Outer_Full-217@0-Ant7-77.701-81.63-≤80-PASS



1-N78-3700-3800-PC2-30-80-M-1-DFT-QPSK-Outer_Full-216@0-Ant7-77.377-81.36-≤80-PASS



1-N78-3700-3800-PC2-30-80-M-3-DFT-16QAM-Outer_Full-216@0-Ant7-76.907-81.31-≤80-PASS



1-N78-3700-3800-PC2-30-80-M-4-DFT-64QAM-Outer_Full-216@0-Ant7-77.203-81.31-≤80-PASS




1-N78-3700-3800-PC2-30-80-M-5-DFT-256QAM-Outer_Full-216@0-Ant7-77.133-81.22-≤80-PASS



1-N78-3700-3800-PC2-30-80-M-6-CP-QPSK-Outer_Full-217@0-Ant7-77.515-81.70-≤80-PASS




1-N78-3700-3800-PC2-30-80-M-7-CP-16QAM-Outer_Full-217@0-Ant7-77.497-81.54-≤80-PASS



1-N78-3700-3800-PC2-30-80-M-8-CP-64QAM-Outer_Full-217@0-Ant7-77.595-81.62-≤80-PASS




1-N78-3700-3800-PC2-30-80-M-9-CP-256QAM-Outer_Full-217@0-Ant7-77.658-81.70-≤80-PASS



1-N78-3700-3800-PC2-30-80-H-1-DFT-QPSK-Outer_Full-216@0-Ant7-77.403-81.19-≤80-PASS



1-N78-3700-3800-PC2-30-80-H-3-DFT-16QAM-Outer_Full-216@0-Ant7-76.966-81.34-≤80-PASS



1-N78-3700-3800-PC2-30-80-H-4-DFT-64QAM-Outer_Full-216@0-Ant7-77.195-81.55-≤80-PASS



1-N78-3700-3800-PC2-30-80-H-5-DFT-256QAM-Outer_Full-216@0-Ant7-77.106-81.07-≤80-PASS




1-N78-3700-3800-PC2-30-80-H-6-CP-QPSK-Outer_Full-217@0-Ant7-77.539-81.62-≤80-PASS




1-N78-3700-3800-PC2-30-80-H-7-CP-16QAM-Outer_Full-217@0-Ant7-77.542-81.65-≤80-PASS



1-N78-3700-3800-PC2-30-80-H-8-CP-64QAM-Outer_Full-217@0-Ant7-77.608-81.71-≤80-PASS



1-N78-3700-3800-PC2-30-80-H-9-CP-256QAM-Outer_Full-217@0-Ant7-77.652-81.58-≤80-PASS



1-N78-3700-3800-PC2-30-90-L-1-DFT-QPSK-Outer_Full-240@0-Ant7-85.820-90.45-≤90-PASS



1-N78-3700-3800-PC2-30-90-L-3-DFT-16QAM-Outer_Full-240@0-Ant7-85.749-90.52-≤90-PASS



1-N78-3700-3800-PC2-30-90-L-4-DFT-64QAM-Outer_Full-240@0-Ant7-85.626-90.47-≤90-PASS



1-N78-3700-3800-PC2-30-90-L-5-DFT-256QAM-Outer_Full-240@0-Ant7-85.858-90.53-≤90-PASS



1-N78-3700-3800-PC2-30-90-L-6-CP-QPSK-Outer_Full-245@0-Ant7-87.499-92.25-≤90-PASS



1-N78-3700-3800-PC2-30-90-L-7-CP-16QAM-Outer_Full-245@0-Ant7-87.794-92.41-≤90-PASS



1-N78-3700-3800-PC2-30-90-L-8-CP-64QAM-Outer_Full-245@0-Ant7-87.609-92.44-≤90-PASS



1-N78-3700-3800-PC2-30-90-L-9-CP-256QAM-Outer_Full-245@0-Ant7-87.486-92.39-≤90-PASS



1-N78-3700-3800-PC2-30-90-M-1-DFT-QPSK-Outer_Full-240@0-Ant7-85.867-90.43-≤90-PASS



1-N78-3700-3800-PC2-30-90-M-3-DFT-16QAM-Outer_Full-240@0-Ant7-85.823-90.51-≤90-PASS



1-N78-3700-3800-PC2-30-90-M-4-DFT-64QAM-Outer_Full-240@0-Ant7-85.590-90.39-≤90-PASS



1-N78-3700-3800-PC2-30-90-M-5-DFT-256QAM-Outer_Full-240@0-Ant7-85.848-90.49-≤90-PASS



1-N78-3700-3800-PC2-30-90-M-6-CP-QPSK-Outer_Full-245@0-Ant7-87.564-92.23-≤90-PASS



1-N78-3700-3800-PC2-30-90-M-7-CP-16QAM-Outer_Full-245@0-Ant7-87.846-92.32-≤90-PASS



1-N78-3700-3800-PC2-30-90-M-8-CP-64QAM-Outer_Full-245@0-Ant7-87.644-92.33-≤90-PASS




1-N78-3700-3800-PC2-30-90-M-9-CP-256QAM-Outer_Full-245@0-Ant7-87.452-92.24-≤90-PASS




1-N78-3700-3800-PC2-30-90-H-1-DFT-QPSK-Outer_Full-240@0-Ant7-85.829-90.41-≤90-PASS



1-N78-3700-3800-PC2-30-90-H-3-DFT-16QAM-Outer_Full-240@0-Ant7-85.755-90.57-≤90-PASS



1-N78-3700-3800-PC2-30-90-H-4-DFT-64QAM-Outer_Full-240@0-Ant7-85.611-90.48-≤90-PASS



1-N78-3700-3800-PC2-30-90-H-5-DFT-256QAM-Outer_Full-240@0-Ant7-85.850-90.51-≤90-PASS



1-N78-3700-3800-PC2-30-90-H-6-CP-QPSK-Outer_Full-245@0-Ant7-87.500-92.25-≤90-PASS



1-N78-3700-3800-PC2-30-90-H-7-CP-16QAM-Outer_Full-245@0-Ant7-87.805-92.38-≤90-PASS



1-N78-3700-3800-PC2-30-90-H-8-CP-64QAM-Outer_Full-245@0-Ant7-87.613-92.29-≤90-PASS



1-N78-3700-3800-PC2-30-90-H-9-CP-256QAM-Outer_Full-245@0-Ant7-87.452-92.30-≤90-PASS




1-N78-3700-3800-PC2-30-100-M-1-DFT-QPSK-Outer_Full-270@0-Ant7-96.594-101.7-≤100-PASS



1-N78-3700-3800-PC2-30-100-M-3-DFT-16QAM-Outer_Full-270@0-Ant7-96.727-101.8-≤100-PASS



1-N78-3700-3800-PC2-30-100-M-4-DFT-64QAM-Outer_Full-270@0-Ant7-96.391-101.7-≤100-PASS



1-N78-3700-3800-PC2-30-100-M-5-DFT-256QAM-Outer_Full-270@0-Ant7-96.591-101.6-≤100-PASS



1-N78-3700-3800-PC2-30-100-M-6-CP-QPSK-Outer_Full-273@0-Ant7-97.441-102.9-≤100-PASS



1-N78-3700-3800-PC2-30-100-M-7-CP-16QAM-Outer_Full-273@0-Ant7-97.510-102.7-≤100-PASS




1-N78-3700-3800-PC2-30-100-M-8-CP-64QAM-Outer_Full-273@0-Ant7-97.399-102.7-≤100-PASS




1-N78-3700-3800-PC2-30-100-M-9-CP-256QAM-Outer_Full-273@0-Ant7-97.631-102.8-≤100-PASS


Band Edge for SA

Test Graphs







1-N78-3700-3800-PC2-30-20-L-4-CP-QPSK-Edge_1RB_Left-1@0-Ant7-3699.98-24.91--37.91-PASS




1-N78-3700-3800-PC2-30-20-L-6-CP-QPSK-Outer_Full-51@0-Ant7-3697.40-20.61--33.61-PASS




1-N78-3700-3800-PC2-30-20-H-2-DFT-QPSK-Edge_1RB_Right-1@50-Ant7-3800.01-23.92--36.92-PASS




1-N78-3700-3800-PC2-30-20-H-3-DFT-QPSK-Outer_Full-50@0-Ant7-3805.47-19.25--32.25-PASS




1-N78-3700-3800-PC2-30-20-H-5-CP-QPSK-Edge_1RB_Right-1@50-Ant7-3800.02-22.92--35.92-PASS




1-N78-3700-3800-PC2-30-20-H-6-CP-QPSK-Outer_Full-51@0-Ant7-3805.37-19.11--32.11-PASS




1-N78-3700-3800-PC2-30-30-L-1-DFT-QPSK-Edge_1RB_Left-1@0-Ant7-3699.99-24.81--37.81-PASS




1-N78-3700-3800-PC2-30-30-L-3-DFT-QPSK-Outer_Full-75@0-Ant7-3694.86-21.89--34.89-PASS




1-N78-3700-3800-PC2-30-30-L-4-CP-QPSK-Edge_1RB_Left-1@0-Ant7-3699.99-24.83--37.83-PASS




1-N78-3700-3800-PC2-30-30-L-6-CP-QPSK-Outer_Full-78@0-Ant7-3694.71-21.56--34.56-PASS




1-N78-3700-3800-PC2-30-30-H-2-DFT-QPSK-Edge_1RB_Right-1@77-Ant7-3800.03-24.18--37.18-PASS




1-N78-3700-3800-PC2-30-30-H-3-DFT-QPSK-Outer_Full-75@0-Ant7-3806.64-21.12--34.12-PASS




1-N78-3700-3800-PC2-30-30-H-5-CP-QPSK-Edge_1RB_Right-1@77-Ant7-3800.03-24.09--37.09-PASS




1-N78-3700-3800-PC2-30-30-H-6-CP-QPSK-Outer_Full-78@0-Ant7-3805.11-20.11--33.11-PASS




1-N78-3700-3800-PC2-30-40-L-1-DFT-QPSK-Edge_1RB_Left-1@0-Ant7-3700.00-12.49--25.49-PASS




1-N78-3700-3800-PC2-30-40-L-3-DFT-QPSK-Outer_Full-100@0-Ant7-3699.93-19.33--32.33-PASS




1-N78-3700-3800-PC2-30-40-L-4-CP-QPSK-Edge_1RB_Left-1@0-Ant7-3700.00-12.00--25.00-PASS




1-N78-3700-3800-PC2-30-40-L-6-CP-QPSK-Outer_Full-106@0-Ant7-3699.98-19.82--32.82-PASS




1-N78-3700-3800-PC2-30-40-H-2-DFT-QPSK-Edge_1RB_Right-1@105-Ant7-3800.00-16.27--29.27-PASS




1-N78-3700-3800-PC2-30-40-H-3-DFT-QPSK-Outer_Full-100@0-Ant7-3800.02-19.99--32.99-PASS




1-N78-3700-3800-PC2-30-40-H-5-CP-QPSK-Edge_1RB_Right-1@105-Ant7-3800.00-16.83--29.83-PASS




1-N78-3700-3800-PC2-30-40-H-6-CP-QPSK-Outer_Full-106@0-Ant7-3800.02-19.39--32.39-PASS




1-N78-3700-3800-PC2-30-50-L-1-DFT-QPSK-Edge_1RB_Left-1@0-Ant7-3699.91-22.26--35.26-PASS




1-N78-3700-3800-PC2-30-50-L-3-DFT-QPSK-Outer_Full-128@0-Ant7-3699.68-21.15--34.15-PASS




1-N78-3700-3800-PC2-30-50-L-4-CP-QPSK-Edge_1RB_Left-1@0-Ant7-3700.00-22.31--35.31-PASS




1-N78-3700-3800-PC2-30-50-L-6-CP-QPSK-Outer_Full-133@0-Ant7-3699.84-20.98--33.98-PASS




1-N78-3700-3800-PC2-30-50-H-2-DFT-QPSK-Edge_1RB_Right-1@132-Ant7-3800.03-22.75--35.75-PASS



1-N78-3700-3800-PC2-30-50-H-3-DFT-QPSK-Outer_Full-128@0-Ant7-3805.18-21.03--34.03-PASS



1-N78-3700-3800-PC2-30-50-H-5-CP-QPSK-Edge_1RB_Right-1@132-Ant7-3800.06-22.50--35.50-PASS



1-N78-3700-3800-PC2-30-50-H-6-CP-QPSK-Outer_Full-133@0-Ant7-3800.01-20.46--33.46-PASS