


# *RoamingMate Bluetooth Receiver Quick Start Guide*

## 1. installation



1: Power jack  
2: Aux-out jack

## 2. Bluetooth pairing

- After installation is done, switch on the Bluetooth pairing feature on your transmitter device
- Searching the pairing name, "Crossroads BT Series"
- Click to pair and start to enjoy wireless music

**Step1:** on location 1,connect to DC5V external power thru the power jack adapter

**Step2:** on location 2, connect the aux-out cable thru the 3.5mm jack to the aux-in jack from the expansion active speaker systems or amplifier

**Crossroads-Comvox Audio**

**Customer service: +88633705808**

**<http://www.comvoxaudio.com>**

## FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help

FCC Notice: This device complies with Part 15 of the FCC Rules

This device and its antenna must not be re-located or operated in conjunction with another antenna or transmitter

FCC ID: RAEXRD-BT

## Canada Statements:

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

IC:11042A-XRDBT

Mod.: XRD-BT