

6.5 Setup Photographs:




7.5 Setup Photographs:






8.5 Setup Photographs:



9.5 Setup Photographs:








10.5 Setup Photographs:


9 kHz-30 MHz











30-1000 MHz










1-18 GHz











18-25 GHz



11.4 Setup Photographs:

30-1000 MHz



1-13 GHz

