



## APPENDIX SETUP PHOTOS

### RADIATED EMISSION SETUP

Test Mode: Normal Operation






**Test Mode: 5Vdc Input**






**RADIATED RF MEASUREMENT SETUP**





**ANTENNA PORT CONDUCTED RF MEASUREMENT SETUP**





**CONDUCTED EMISSION SETUP**

