

RC007 specification

Products specification & compose Use Notice

Products specification & compose:

This is a low consumer universal encode circuit which make by COMS (working with SC2272, 12 bit 3 condition encode); 315MHz +/- 200KHz SAW; ASK modulate fashion. 315MHz regeneration circuit; User can press button of transmitter (transmit 315MHz wireless brewage signal) and looking for receiver that's attach with beverage (receive 315MHz wireless brewage signal and intercede, then reach to sound & light indicate target via control function circuit), let user know the beverage place by sound & LED light from receiver. The system requested to remote distance <20m (the circumstance with commonly jam); Guarantee to without repeat code in 150,000pcs.

	RC007 (Remote Controller Parts)	
	Receiver	Transmitter
Voltage	6V/DC	12V/DC
Current	<120mA	<13mA
Frequency	315MHz ± 200KHz	315MHz ± 200KHz
Sensitive	>20m	
Circumstance temperature	-25°C-55°C	
Modulation	ASK	

USE

1. Please sure the battery is valid, then put power switch on for standby situation.
2. Press red button of transmitter, the wireless signal will transmitted at same time.
3. The receiver will get signal at availability range and perform with sound & light.

Note:

The battery can support receiver activity up 50 times.

The receiver hasn't automatic power off function, it's in working situation and consume power when put switch on till power off. So please off the switch if equipment isn't used.

In normal use, please change to new battery if find to remote control distance become short, sound volume low and light low. Please open the battery cover by and change 4 new battery with same model (AAA, 1.5V).

Please put receiver on the table or other suitable place, Don't allowed put receiver on

the place with much shield for avoid to receive signal fault.

The new transmitter's battery can use in one year if activity in 10 times one day.

In normal use, please change to new battery if find to remote control distance become short. Please open the cover by screwdriver and change new battery with same model (27A 12V).

The transmitter can hang on the clothes by clasp.

Don't allow to inundate, beat, stress...