


Universal/Wireless Hands-Free Cell Phone Kit

#2686

© 2003 E & B Giftware, LLC



Requires 1 "AAA" battery (not included)

- | | |
|------------------|------------------|
| 1. Battery Cover | 5. Earphone Jack |
| 2. On/Off Button | 6. Receiver Port |
| 3. Antenna | 7. Metal disk |
| 4. LED Light | 8. Magnetic Base |

BATTERY INSTALLATION

Slide battery cover (1) off. Insert 1 "AAA" according to the polarity drawing. Replace battery cover.

SET UP

1. Tune your car radio to FM88.6 MHz ~~(±0.1)~~ ($\pm 0.3\text{MHz}$) radio frequency.

HINT: Once you have determined the correct radio frequency, pre-set this frequency to one of the vehicle's pre-select radio buttons.

2. Adjust the radio speaker volume.

3. Depress the on/off button (2) to the on position, this will mute the radio sound and the red LED light (4) will light.

Note: If the radio sound can still be heard, change the frequency ± 0.1 MHz.

4. Using the clip, attach this product to your cell phone. The receiver port (6) should be placed over the receiver of your cell phone.

5. Extend the antenna (3).

6. **IMPORTANT:** It is necessary to determine the location in your vehicle where this product works optimally. The direction of the antenna often affects the function of this product. Try several locations until the best reception location is determined.

7. The magnetic base (8) can be used to mount your cell phone to your vehicle's dashboard or console. Simply remove backing of double-sided tape and adhere base to desired location. Lay phone on base and it will be held in position by magnet.

NOTE:

Some cell phones may not stick to the magnetic base. In this instance, affix the small metal disk (7) (included) to the bottom of your cell phone by removing the backing of the double-sided tape.

To maintain optimum working condition, avoid excessive exposure to sunlight, heat and humidity.

TO USE

While driving, you can be listening to the radio. When your cell phone rings, depress the pre-selected radio button with the pre-set radio frequency. Depress the product's on/off button to "on" position and depress

your model) to receive a call. The calling party's voice will now be transmitted via the vehicle's radio speakers. In most instances, you will need to adjust/increase the radio volume to hear the calling party clearly.

EARPHONE JACK

An earphone jack (5) is provided for privacy when talking. An earphone is required to use this feature. The earphone is not included with this kit. To use, plug earphone into earphone jack (5). Product must be in the "on" position to operate.

SPECIFICATION

Frequency: ~~88.6 MHz (± 0.1)~~ 88.6 MHz (± 0.3 MHz)

Ratio Wave Type: F3E

Power Requirements: Battery: AAA 1.5V

Antenna: Rod ANT/Plate ANT

Field Strength: Diameter 3M with less than 500uV/m

Operating Temperature: -10°C~50°C / 14°F~122°F

Dimensions: 68x85x40mm

Modulation Type: FM

Transmission Type: X-tal

Communication Type: Simplex

NOTE

- Non-rechargeable batteries are not to be recharged
- Rechargeable batteries must be removed before recharging
- Rechargeable batteries only to be recharged under adult supervision
- Different types of batteries must not be mixed
- New and used batteries not to be mixed
- Exhausted batteries to be removed
- Do not dispose of battery in fire; battery may explode or leak
- Do not dispose of product in fire; battery may explode or leak

CANADA:

ACI/STARCASE CANADA

5900 Keaton Crescent, Mississauga, Ontario L5R 3K2

UNITED KINGDOM:

STARCASE (UK) LTD.,

Wainwright Road, Worcester WR4 9FA

UNITED STATES:

E&B GIFTWARE, LLC,

585 Oak Ridge Road, Hazleton, PA 18202

PS2686IS01ENBRA

FCC Information

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.