

Universal Bluetooth Audio Receiver and FM Transmitter


Quick Start Guide



model ABF01F

qsg Q10464 Copyright © 2018 Aluratek, Inc. All Rights Reserved.

Product Highlights



USB Charging Port (5V / 2.1A)

USB Charging Port (5V / 1.0A)

Frequency Display

Previous Button

Next Button

Short Press: Answer Call / Reject Call / Redial Call / Play / Pause

Long Press: Enter Frequency Setting Mode

Rotate Dial: Volume Control / Frequency Search

Microphone

Operation

Control Functions	
Function	Operation
How to power on	Plug the device into the car's cigarette lighter adapter
How to play and pause music	Short press  button to play Press again  to pause
How to adjust the volume	Adjust the volume by turning the dial 
How to select music	Press  to play the next song Press  to play previous song

Operation

Control Functions	
Function	Operation
How to answer and end a phone call	Short press  button to answer an incoming call
	Short press  button to end the call
	Long press  button to refuse an incoming call
	Double press  button to redial the last phone number

Operation

Setup connection between ABF01F and car FM stereo:

ABF01F powers on automatically when it is inserted into car cigarette lighter power.

- On the car stereo, select a frequency that is not used (static sound) between 87.5 ~ 108Mhz
- On ABF01F, long press the  button to change into frequency setting mode.
- Rotate the  button to adjust the frequency to the same frequency you selected in step 1.
- ABF01F is now synced to your car FM stereo.

Operation

Pairing your Bluetooth device to ABF01F

- ABF01F will start in pairing mode when it is powered.
- Active your device's Bluetooth function and set your device to search for Bluetooth device. Select ABF01F when it is found.
- Your Bluetooth device is now connected to ABF01F. You may now stream your music from your Bluetooth device to your car FM stereo.

Radio and TV Interference Statement

WARNING!!! This equipment has been tested and found to comply with the limits of a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by whatever measures may be required to correct the interference.

Warranty

Aluratek warrants this product against defect in material or workmanship for **1 YEAR** from the date of purchase.

This warranty becomes invalid if the factory-supplied serial number or "warranty void" sticker has been removed or altered on the product.

This warranty does not cover:

A) Cosmetic damage or damage due to acts of God

B) Accident, misuse, abuse, negligence or modification of any part of the product.

C) Damage due to improper operation or maintenance, connection to improper equipment, or attempted repair by anyone other than Aluratek.

D) Products sold AS IS or WITH FAULTS.

IN NO EVENT SHALL ALURATEK'S LIABILITY EXCEED THE PRICE PAID FOR THE PRODUCT FROM DIRECT, INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THE PRODUCT, IT'S ACCOMPANYING SOFTWARE, OR IT'S DOCUMENTATION.

Aluratek makes no warranty or representation, expressed, implied, or statutory, with respect to it's products, contents or use of this documentation and all accompanying software, and specifically disclaims it's quality, performance, merchantability, or fitness for any particular purpose. Aluratek reserves the right to revise or update it's product, software or documentation without obligation to notify any individual or entity.

Technical Support

If you need further assistance, please contact the Aluratek support department for troubleshooting prior to returning this device.

E-mail: support@aluratek.com

Web: www.aluratek.com/helpdesk

Local (Irvine, CA): **714-586-8730**

Toll free: **1-866-580-1978**

Récepteur audio universel Bluetooth et émetteur FM


Guide de démarrage rapide



modèle ABF01F

qsg Q10464 Copyright © 2018 Aluratek, Inc. All Rights Reserved.

Caractéristiques du produit



Port de charge USB (5 V/2.1 A)

Port de charge USB (5 V/1.0 A)

Affichage de la fréquence

Bouton Précédent

Bouton Suivant

Appuyez brièvement: répondre à l'appel / refuser l'appel / recomposer le numéro / faire jouer/mettre en pause

Appuyez longuement: entrez le mode Réglage de fréquence

Tourner le cadran: contrôle du volume/recherche de fréquence

Microphone

Operation

Contrôlez les fonctions	
Fonction	Operation
Comment allumer l'appareil	Branchez l'appareil dans l'adaptateur de l'allume-cigarette
Comment faire jouer et mettre en pause la musique	Appuyez brièvement sur le bouton Jouer. Appuyez de nouveau pour mettre en pause.
Comment ajuster le volume	Ajustez le volume en tournant le  cadran.
Comment sélectionner de la musique	Appuyez  pour faire jouer la prochaine chanson. Appuyez  pour faire jouer la chanson précédente.

Operation

Contrôlez les fonctions	
Fonction	Operation
Comment répondre et terminer un appel	Appuyez brièvement  sur le bouton pour répondre à un appel entrant
	Appuyez brièvement  pour terminer l'appel
	Appuyez longuement  pour refuser un appel entrant
	Appuyez deux fois  pour recomposer le dernier numéro de téléphone

Operation

Réglage de la connexion entre l'ABF01F et la stéréo FM du véhicule:

L'ABF01F s'allume automatiquement lorsqu'il est inséré dans l'allume-cigarette.

- Sur la stéréo du véhicule, sélectionnez une fréquence qui n'est pas utilisée (son sans parasites) entre 87,5 et 108 MHz
- Sur l'ABF01F, appuyez longuement sur le  bouton pour changer vers le mode Réglage de fréquence.
- Tournez le  bouton pour ajuster la fréquence à la même que vous avez sélectionnée à l'étape 1.
- L'ABF01F est maintenant synchronisé à la stéréo FM de votre véhicule.

Operation

Jumelage de votre appareil Bluetooth à l'ABF01F

- L'ABF01F débutera en mode Jumelage lorsqu'il sera allumé.
- Activez la fonction Bluetooth de votre appareil et réglez votre appareil pour qu'il cherche l'appareil fonction Bluetooth. Sélectionnez l'ABF01F lorsqu'il a été trouvé.
- Votre appareil Bluetooth est maintenant connecté à l'ABF01F. Vous pouvez maintenant diffuser de la musique de votre appareil Bluetooth à la stéréo FM de votre véhicule.

Énoncé d'interférence avec la réception radio et télévisée

AVERTISSEMENT!!! Cet appareil a été testé et est conforme aux limites d'un appareil numérique de Classe B, en vertu de la Section 15 des règles CFC. Ces limites ont été conçues pour assurer une protection raisonnable contre de telles interférences néfastes dans une installation résidentielle.

Cet équipement génère, utilise et peut émettre de l'énergie de fréquence radio. S'il n'est pas correctement installé et utilisé, il peut causer des interférences nuisibles dans les communications radio. Toutefois, il est impossible de garantir que de telles interférences ne surviendront pas dans une installation particulière. Si cet équipement cause des interférences nuisibles à la réception radio ou télévisée, laquelle peut être déterminée en éteignant et allumant l'équipement, on suggère à l'utilisateur d'essayer de corriger l'interférence par quelques mesures que ce soit afin d'éliminer les interférences.

Garantie

Aluratek garantit se produit contre les défauts de matériel et de fabrication pour une période de **1 an**, à compter de la date d'achat.

Cette garantie devient invalide si le numéro de série de l'entreprise ou l'étiquette « garantie annulée » a été retirée ou modifiée sur le produit.

Cette garantie ne couvre pas :

A) Dommages de fabrication apparente ou dommages à la suite de cas imprévus

B) Accident, mauvaise utilisation, abus, négligence ou modification de toute pièce du produit.

C) Dommages résultant d'un fonctionnement ou entretien inadéquat, connexion à un équipement inadéquat, ou tentative de réparation par une personne, autre que Aluratek.

D) Les produits sont venus TELS QUELS ou SANS DÉFAUT.

EN AUCUN CAS, LA RESPONSABILITÉ D'ALURATEK N'EXCÈDE LE PRIX PAYÉ POUR LE PRODUIT À LA SUITE D'UN DOMMAGE DIRECT, INDIRECT, PARTICULIER OU CONSÉCUTIF RESULTANT DE L'UTILISATION DU PRODUIT, DE SES LOGICIELS D'ACCOMPAGNEMENT OU DE SA DOCUMENTATION.

Aluratek ne fait aucune déclaration et ne donne aucune garantie expresse, implicite ou légale relative à ses produits, son contenu ou son utilisation de la documentation et de tous ses logiciels d'accompagnement, et renonce spécifiquement à la qualité, au rendement, à la qualité marchande et à la convenance. Aluratek se réserve le droit de réviser ou de mettre à jour son produit, logiciel ou documentation sans l'obligation d'aviser tout individu ou entité.

Support Technique

Pour toutes autres questions, veuillez communiquer avec le service de soutien Aluratek avant de retourner votre appareil.

Courriel: support@aluratek.com

Site Web: www.aluratek.com/support

Numéro local: (Irvine, CA): **714-586-8730**

Numéro sans frais: **1-866-580-1978**

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.