

# User Guide

## 3 Wireless Keyboard

Please read this manual carefully before using the keyboard.

### System available

Compatible with IBM \ PC and Windows<sup>TM</sup> keys,  
Microsoft®Windows®95/98/2000/NT/XP.

### INSTALLATION

- 1 ➤ Shut down and turn off the computer.**
- 2 ➤ Pull out the primary keyboard.**
- 3 ➤ Plug the round PS2 or USB connector into the computer's round PS2 or USB port. (Refer to picture 1-1)**
- 4 ➤ Battery Installing:**
  - 1) Overturn the keyboard and take down the cover of the keyboard battery compartment.(Refer to picture 1-2)**
  - 2) Insert two “AA” 1.5V batteries correctly into the keyboard battery compartment. (Refer to picture 1-3)**
- 5 ➤ Channel Setting**
  - 1) Turn on the computer.**
  - 2) Gently press the key “connect” on the top of receiver after the windows operation system is fully running. (Refer to 1-4)**

**3) Press the key “connect” on the right of keyboard and then test the connection by pressing freely one key of the keyboard . If it works properly, the lights on the receiver will flash indicating a strong signal. (Refer to 1-5)**

**This device complies with Part 15 of the FCC Rules.**

**Operation is subject to the following two conditions:**

**(1) this device may not cause harmful interference.**

**(2) This device must accept any interference received, including interference that may cause undesired operation.**

**Warmly Reminding :**

**1) Please repeat step 2) & 3) if you found the keyboard is clashed by other products.**

**2) Please repeat step 2) & 3) to reset the communication channel whenever you change the batteries.**

**Keyboard Trouble shooting :**

**1. Computer can't get the keyboard registered on the receiver.**

- **Check the connection and ensure that the keyboard port of the receiver is correctly plugged into the computer.**

- **Ensure that the PS/2 port setting is correct. (Refer to the pc**

**instruction)**

**2. Keyboard can not work after installing completely.**

- **Check the keyboard and ensure the batteries correctly plugged into the battery compartment.**
- **Check and ensure the keyboard projector and the receiver rein the same channel.**

**3. If it becomes slow or even quit working.**

- **Check and change a new battery if the old one is in the low power situation.**
- **It will be form a barrier prohibiting smooth operation that the receiver is around high-radiancy area, check and make it far from that.**
- **Check and ensure that you already correctly remove the existing keyboard software in your computer.**

**Caution:**

**Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.**

**Note:**

**Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:**

- Reorient or relocate the receiving antenna.**
- Increase the separation between the equipment and receiver.**
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.**
- Consult the dealer or an experienced radio/TV technician for help.**