

GW0301 工作原理:

1. Voltage of 2.4GHz wireless Transmitter Model is 5V.
2. Frequency: CH1/2414MHz;CH2/2432MHz; CH3/2450MHz, CH4/2468MHz
3. The Video and Audio connect with 3 and 4 on model separately, Power supply connect with 1 and choose the Frequency (Channel) through the Switcher K.