

2.4GHz Wireless B/W CAMERA

INSTRUCTION MANUAL

MODEL NO.:GW 0301



FCC Notice To Users


Goodwill is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

**Please read these instructions completely
before operating this unit**

Camera Features:

1. Microphone:
This unit has a built-in microphone that gathers sound at the camera location and transmits it to the television or monitor:
2. DC power (black).
3. Camera with night light compensation LED and weather proof outdoor housing
4. Handle with care. Do not place in a location subject to vibration.
5. Do not place camera in a location subject to direct sunlight or high light. Never aim camera directly into the sun.
6. Make sure the power to the television is turned off and the power supply is unplugged from the power source when connecting the system.
7. Picture for change channel



Security Camera Specifications:

Image sensor:	1/4" B/W CMOS
Picture pixels:	100000
Video System	NTSC / PAL
Transmitter Frequency	2414-2468MHz
Lens:	3.6mm
Min illumination:	0.5Lux
Microphone Sensitivity	1 – 2 meters
Power Supply:	DC 9V/350mA
Power Consumption:	1Watt
Dimensions:	45X 110X 90mm