



Franklin®



Caution: The user is cautioned that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.



SPEED TRACKER PRO



Franklin®



Speed Tracker Pro


ITEM NO. 6809



Parts List:




(A) Pitcher's Mound (1pc)




(B) Sensor (1pc)



(C) Display (1pc)
Replacement Part
6809-R2



(D) Foot Pad (1pc)
Replacement Part
#6809-R1




BATTERY & ASSEMBLY INSTRUCTIONS

Step 1: Insert Batteries:

Display: Requires 3 "AAA" size batteries (not included)
Do not mix old and new batteries.
Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.

Sensor: Requires 3 "LR44" size batteries (included)
Do not dispose of batteries in fire, batteries may explode or leak.



Display



Sensor

Step 2: Attach the Foot Pad to the Display

Step 3: Slide the Display in the grooved slots of the Pitcher's Mound. The Foot Pad should extend outwards in front of the Mound.

Step 4: Attach the Sensor to a glove or backstop. (not included) (See Figure 1)



Figure 1

TRACK YOUR SPEED:

Step 1: Turn on the glove sensor

Step 2: Press the "on" button located on the pitch plate. Then select the distance: 24ft, 36ft, 46ft, 54ft or 60.6ft (7.3m, 11m, 14m x 16.5m or 18.5m).

NOTE: For accuracy, measure and match the selected distance to the distance from the pitch plate to the catcher's glove w/sensor.

Step 3: Place one foot on the Foot Pad. The display should flash "HHH". Pitch the ball.

Note: Lift foot off the foot pad upon the release of ball. When the ball triggers the sensor in the glove it will transmit the actual MPH to the LED screen.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**PRODUCT NOT DESIGNED FOR
USE IN WET CONDITIONS**

Major League Baseball trademarks and copyrights are used with permission of Major League Baseball Properties, Inc. Visit MLB.com

Franklin Sports Inc.
Stoughton, MA 02072
Made in China

For Replacement Parts Call:
1-781-341-5178 or 1-800-225-8649
OR visit www.franklinsports.com