

# Manual Book

**Product Specification**      **One key download**

**What is MokaBlue II ?**

**Search MokaBlue II**

MokaBlue II is a small type of communication product, Users can insert SIM card of any GSM, it can make all IOS and Android equipment to increase the language speaking, message transceiver and internet access function.

## **Main Advantages:**

1. Can make the iTouch in Tel function;
2. iPhone and Android can become double card mobile;
3. iPhone and Android pads can call and enjoy internet at anytime and anywhere;
4. MokaBlue II is small and easy to portable; separate with other equipment inside 10m will not be affected.

## **MokaBlue II Quick Start**

Keyboard and Parts

Forcing Shutdown Key

Earphone Hole

SIM Card Slot

Sling Hole

Power Key

Charge Hole

## **Charge, Install SIM Card**

1. Use charger or charging by USB with DC 5V
2. Insert the SIM card by notch-in, metal touching-down then start to use.

## **Switch On, Switch Off**

1. Under switch off, hold down power key in 3 seconds, the equipment will be inside the on- processing with vibration;
2. Under switch on, hold down power key in 3 seconds, the equipment will be inside the off- processing with vibration;

## **Indicator light**

Hold down power key in 3 seconds to switch on, LED light will appear red, yellow and green colors alternating twinkle, it means it's in searching the signal. If SIM card is normal, the LED light will twinkle one time by six seconds, now the machine can be used; If the SIM card is useless or not be inserted, LED light will twinkle one time by one second, now the machine can not be used, then please check the SIM card.

## **LED Indicator Light Color Meaning**

1. Green when the power in 66% - full;
2. Blue when the power in 33%-66%;
3. Red when the power under 33%;
4. Red twinkle urgently when the power under 10%.

## **Attention**

Switch on the machine after inserted the SIM card. It will be recognized useless card to insert the SIM card under switching on and can not be read the card effectely, will need to switch off and restart it again then can be used in normally.

More detail please go on our website to check:

[www.DIWEINUO.com](http://www.DIWEINUO.com)

## **Guarantee Card**

Model:

Bought Date:

Invoice No.:

Technical Support:

Customer Signature (Stamp):

Distributor Signature (Stamp):

Contact:

(No distributor's signature or stamp will not in guarantee service)

## **User Instructions**

1. The guarantee card is the most important certificate for after-sale service under guarantee time, the users need to write the guarantee card details completely in buying and please keep it well.
  2. The bought date is according to the distributor's invoice or reception date.
  3. Service Promise: If the machine in problem after sale in 7 days under the outside looking is not be damaged, users can choose return it back or change the goods, we will service in free repairing under the outside looking damaged; After sale in one year from bought date happened function problems or the user not satisfied with free changeable and free repairing, our company will do the paid service and just collect the parts costing.
  4. Our company will do the paid service under guarantee(Include "Three pack" validity period) and in the same time not enjoy "Three pack" service;
- ① Can not show the effective guarantee card, invoice ,reception

or the machine code damaged;

- ② The bought date or the distributor(effective stamp) etc. didn't wrote or altered the guarantee card;
- ③ Cause of force majeure(Fire,Thunder,Earthquake.obnormal electric pressure) caused problems or damaged;
- ④ Under transporting or the loading caused the problems or damaged;
- ⑤ Human causing damaged and include using under abnormal work surrounding, not follow the use instructions or attention matter, connect not properly, connect to not suitable power or not follow the user instructions mentioned of under the computer environment caused the problems or damaged;
- ⑥ No company's authorized then unload, repair and refit;
- ⑦ Under normal using damaged, old or other reason caused broken, rust or dip;
- ⑧ Not belong to our company's products(Fake goods);
- ⑨ Outside looking damaged, face scratched not belong to guarantee

5. Please take the guarantee card, invoice or reception to our company's directed repair station to repair. If the problems can not be solved properly, please call or send letter to our service department, we will solve it for you in the shortest

time.

6. Please use the origin or vibration protection packing to send to our repair station to repair, if damaged under the transporting cause of not using the protection packing will not in the guarantee range, the charges for the transportation will be paid by the user.
7. This guarantee promise paid range just limit under change, repair the damaged products, not include production problem caused the other indirect damage.
8. Above final interpretation power is belong to

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This device and its antenna(s) must not be co-located or operating in conjunction with any other antenna or transmitter.

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio

communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

#### FCC RF Exposure Information and Statement

The SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. Device types: MokaBlue (FCC ID: RHFDWNMOKABLUE) has also been tested against this SAR limit. The highest SAR value reported under this standard during product certification for use properly worn on the body is 0.730W/kg. This device was tested for typical body-worn operations with the back of the handset kept 5mm from the body.



To maintain compliance with FCC RF exposure requirements, use accessories that maintain a 5mm separation distance between the user's body and the back of the handset. The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly.

The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided