

OPERATING MANUAL

FCC ID:RKGRF988
WIRELESS HEADPHONE

RF988





TRANSMITTER



WIRELESS HEADPHONE



CONNECTION WAY

1. Plug into the adapter
2. Power on the transmitter with DC plug
3. Connect the transmitter to audio source with an audio cable
4. Turn on headphones to listen to the audio
5. Press the power key once on headphones to change channels.

FEATURES

- RF Silent Disco wireless headphone with three channels
- Operation distance up to 300m
- With reception through wall and ceiling
- One transmitter can connect to more than numerous headphones simultaneously
- Power saving system makes the headphone power off automatically if no signal detected for 10 minutes

TECHNICAL SPECIFICATION

System:	UHF/RF
Carrier frequency:	926MHZ,926.8MHZ,927.5MHZ
Modulation:	FM
Mode:	Stereo
S/N ratio:	≥75dB
Distortion:	<1%
Frequency response:	50-15000HZ
Impedance:	32 Ohms
Sensitivity:	-88dBm±3dB

IMPORTANT REGULATORY INFORMATION

This device complies with Part 15 of the FCC Rules: Operation is subject to the following two conditions:

1. This device may not cause harmful interference and
2. This device must accept any interference that is received, including any interference that may cause undesired operation.

WARNING:

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.