

TT3058A Part locations:

GPS Module




Top view

GPS Module



Bottom view

HPA / LNA Board



Top view

HPA / LNA Board



Bottom view