

# Wireless Headset<sup>BLUCLIP</sup> User Guide



FCC Notice:  
This device complies with part 15 of the FCC rules.



- (vii) signal reception problems (unless caused by defects in material and workmanship);
- (viii) damage the result of fire, flood, acts of God or other acts which are not the fault of HTK and which the Product is not specified to tolerate, including damage caused by mishandling, shipping and blown fuses;
- (ix) consumables (such as fuses); or
- (x) any Product which has been opened, repaired, modified or altered by anyone other than HTK or a HTK authorized service center.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

**Caution:**

The user is cautioned that changes or modifications not expressly approved by the party responsible for compliance could void the warranty and users' authority to operate the equipment.

**Note:**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off

and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help.

**FCC Radiation Exposure Statement:**

To comply with the FCC RF exposure compliance requirements, this device must not be co-located or operating in conjunction with any other antenna or transmitter.

**COPYRIGHT TRADEMARK RECOGNITION**

HTK is a registered trademark of HTK Corporation.

The Bluetooth® word mark and logos are owned by the Bluetooth® SIG, Inc. and any use of such marks by HTK Corp. is under license. All other marks are held by their respective owners. Copyright ©2007 HTK Corp. All rights reserved.

subject Product

(i) is returned, with transportation prepaid, to a HTK authorized service center within the one year warranty period, and

(ii) is accompanied by a proof of purchase in the form of a bill of sale or receipted invoice which evidences that the subject Product is within the one year warranty period ("Proof of Purchase". After the one year warranty period, you must pay all shipping, parts and labor charges. This limited warranty does not cover and is void with respect to the following:

(i) any Product which has been improperly installed, repaired, maintained or modified;

(ii) any Product which has been subjected to misuse (including any Product used in conjunction with hardware electrically or mechanically incompatible or used with accessories not approved by HTK), abuse, accident, physical damage, abnormal operation, improper handling, neglect, exposure to fire, water or excessive moisture or dampness or extreme changes in climate or temperature;

(iii) any Product operated outside published maximum ratings;

(iv) cosmetic damage;

(v) any Product on which warranty stickers or Product serial numbers have been removed, altered, or rendered illegible;

(vi) cost of installation, removal or reinstallation;

## CONSUMER LIMITED WARRANTY

HTK Corp. ("HTK") offers you a limited warranty that the enclosed product or products (the "Product") will be free from defects in material and workmanship for a period that expires one year from the date of sale of the Product to you, provided that you are the original end-user purchaser of the Product and provided that your purchase was made from an authorized supplier. Transfer or resale of a Product will automatically terminate warranty coverage with respect to that Product. This limited warranty is not transferable to any third party, including but not limited to any subsequent purchaser or owner of the Product. This limited warranty is applicable only to end users in the United States and Canada.

HTK shall, at its sole and absolute discretion, either repair or replace a Product (which unit may use refurbished parts of similar quality and functionality) if found by HTK to be defective in material or workmanship, or if HTK determines that it is unable to repair or replace such Product, HTK shall refund the purchase price for such Product, provided that the

## TABLE OF CONTENTS ÍNDICE

|   |   |
|---|---|
| Introduction. . . . .                           | 1 |
| Getting to know your Wireless Headset . . . .   | 2 |
| Charging the battery. . . . .                   | 3 |
| Pairing with a compatible phone. . . . .        | 3 |
| Activating the Bluetooth® from your phone . . . | 4 |
| Reconnecting to a compatible phone. . . . .     | 4 |
| Performing basic functions. . . . .             | 5 |
| Power ON. . . . .                               | 5 |
| Power OFF. . . . .                              | 5 |
| Answer a call . . . . .                         | 5 |
| Adjust phone volume . . . . .                   | 5 |
| Re-dial . . . . .                               | 5 |
| Mute/unmute a call. . . . .                     | 5 |
| Reject a call . . . . .                         | 5 |
| End a call . . . . .                            | 5 |
| Switch a call . . . . .                         | 6 |
| Voice Dialing. . . . .                          | 6 |
| Performing advanced functions. . . . .          | 6 |
| Important information . . . . .                 | 6 |
| Maintenance. . . . .                            | 6 |
| Battery. . . . .                                | 7 |
| Power Supply . . . . .                          | 7 |
| Cars with air bags. . . . .                     | 7 |

Frequently Asked Questions . . . . . 8

Other instructions. . . . . 9

Q: Is it necessary to reconnect the two devices when there is an interruption on the link between my mobile phone and my Wireless Headset<sup>BLUCLIP</sup>?

A: It varies depending on the type of mobile phone. Some mobile phones will reconnect automatically if both devices are within the effective distance. Some mobile phones must be physically reconnected.

Q: Why is there noise in my Wireless Headset<sup>BLUCLIP</sup>?

A: When the distance between your mobile phone and your Wireless Headset<sup>BLUCLIP</sup> exceed the effective distance, background noise may occur. If the signal for your mobile phone is poor in your area, your Wireless Headset<sup>BLUCLIP</sup> may likewise receive poor quality reception.

Q: What can I do if my Wireless Headset<sup>BLUCLIP</sup> sound quality is poor?

A: Try adjusting the volume of your mobile phone, or your Wireless Headset<sup>BLUCLIP</sup>. Also, check the quality of the signal on your mobile phone in your area.

## Other instructions

Different Bluetooth<sup>®</sup> wireless technology enabled mobile phones may have been designed in different ways, and therefore, may function differently. The instructions provided in this user guide may not cover all information. For further information please refer to your mobile phone user guide.

## Frequently Asked Questions

Q: Can my Wireless Headset<sup>BLUCLIP</sup> be used for all brands of mobile phones?

A: Yes, as long as the mobile phone has built-in Bluetooth<sup>®</sup> Voice Gateway functionality.

Q: How far is the distance between my Wireless Headset<sup>BLUCLIP</sup> and a Bluetooth<sup>®</sup> wireless technology enabled mobile phone?

A: The distance (without barriers) is 33ft. (10M).

Q: Can another wireless mobile phone user hear my conversation?

A: No. Through pairing, you have created a secure link between your mobile phone and your Wireless Headset<sup>BLUCLIP</sup>.

Q: Why is my mobile phone unable to find the Wireless Headset<sup>BLUCLIP</sup>?

A: Your mobile phone should be able to find the Wireless Headset<sup>BLUCLIP</sup> when it is in pairing mode. (Refer to "Pairing with a compatible phone" on page 3 for details).

Q: Is pairing needed each time I use my Wireless Headset<sup>BLUCLIP</sup>?


A: No. The pairing information is stored in both devices, even if one or both of them have been turned OFF.

## Introduction

Congratulations on the purchase of your Wireless Headset<sup>BLUCLIP</sup> featuring Bluetooth<sup>®</sup> wireless technology! The Wireless Headset<sup>BLUCLIP</sup> is comfortable and easy to use.





Bluetooth<sup>®</sup> wireless technology is a short-distance wireless communication technology. The range of operation between Bluetooth<sup>®</sup> wireless technology devices is about 33ft. (10M). Bluetooth<sup>®</sup> wireless technology does not require line-of-sight and can transmit through walls and other non-metal obstacles. Thick or reinforced concrete may limit the range.

## Package contents



Note: The illustrations above are for reference only.  
Your individual package contents may vary with kit configuration.

**Getting to know your Wireless Headset<sup>BLUCLIP</sup>**  
Please refer to the following table for parts identification.

|   |  |   |   |
|---|--|---|---|
| 1 |  | Multi Function button turns the headset ON and OFF, and answers, ends, and rejects calls. |  |
| 2 |  | Volume + increase button  |   |
| 3 |  | Volume - decrease button  |   |
| 4 |  | LED Indicator   |   |
| 5 |  | Charging jack for AC Adapter  |   |
| 6 |  | Earpiece  |   |
| 7 |  | Microphone  |   |
| 8 |  | Shirt Clip  |   |

Kit Contents: Wireless Headset<sup>BLUCLIP</sup>, Quick Start Guide, and Warranty Card. Optional Accessories: AC Adapter, and USB Charging Cable.

spray liquid or cleansers on the surface of your Wireless Headset<sup>BLUCLIP</sup>. Spray the cleanser on the soft cloth and then clean the device with it.

- Do not store in a dusty place or in very high temperatures nor low temperatures.
- Do not disassemble this product, as this may damage it.
- Avoid rough treatments such as ropping, knocking, or shaking this product.

### Battery

- When using your Wireless Headset<sup>BLUCLIP</sup> for the first time, ensure the battery has been fully charged for at least 2 hours.
- To avoid damaging the battery only plug the AC Adapter into an appropriate electrical outlet.
- To avoid danger of explosion, do NOT dispose of batteries in fire.

### Power Supply

- Hold the AC adapter, not the cable, when you remove the AC adapter from the power socket.

### Cars with air bags

Do NOT place your Wireless Headset<sup>BLUCLIP</sup> on top of an air bag or within the area an air bag can reach when it is deployed. Doing so may cause the device to eject and result in serious harm to the driver or passengers.

### Switch a call

Switch call from a phone to your Wireless Headset<sup>BLUCLIP</sup> by quickly pressing both the Multi Function button

### Voice Dialing

(phone dependent feature) Activate the voice dialing feature by pressing the Multi Function button for 1 second. A tone will sound indicating to begin saying the voice tag. The phone will play the voice tag and dial the related phone number.

### Performing Advanced Call Functions

#### Hold a call

Place a call on hold by pressing the Multi Function button for 1 second.

#### Answer second call

Hold active call and answer second call by pressing the Multi Function button for 1 second.

#### Retrieve a call on hold

Retrieve the held call and hold active call by pressing the Multi Function button for 1 second.

### Important information

#### Maintenance

- Disconnect the charger and power OFF the device when you clean it. Do NOT directly

### Charging the battery

The battery must first be charged for at least 2 hours prior to use. Once charged, it provides up to 5 hours talk time and up to 100 hours standby time. When the red indicator light flashes and a warning sound beeps, you must recharge the battery.

1. Connect the AC Adapter to your Wireless Headset<sup>BLUCLIP</sup>.
2. Plug the AC Adapter into a wall outlet.  
Note: The red LED will be turned on while charging and the blue LED will be turned on when charging is complete.
3. Unplug the charger from your Wireless Headset<sup>BLUCLIP</sup>.

### Pairing with a compatible phone

Note: Ensure your phone is turned on and is within 33ft. (10M) of your Wireless Headset<sup>BLUCLIP</sup>.

1. Turn on your Wireless Headset<sup>BLUCLIP</sup> by pressing and holding the Multi Function button for 8 seconds.

Note1: The LED Indicator will illuminate blue during this process.

Note2: If you turn on your Wireless Headset<sup>BLUCLIP</sup> for the first time, it proceeds into Pairing mode immediately.

## Activating the Bluetooth® connection from your phone

1. Execute the search function on your mobile phone to search for Bluetooth® devices.

Consult your phone user guide for specific instructions.

2. Select BLUCLIP from the search results list.

3. Enter the code (or passkey) 0000 to pair your Wireless Headset<sup>BLUCLIP</sup> with your phone.

4. If the pairing is successful, the blue indicator light will flash 10 times rapidly before entering Standby mode.

5. If the blue indicator light remains lit, retry pairing.

## Reconnecting to a compatible phone

If your Wireless Headset<sup>BLUCLIP</sup> is out of the 33ft. (10M) range for over 10 minutes, reactivate the connection by quickly pressing the Multi Function button.

## Performing basic functions

### Power ON

Power ON by pressing and holding the Multi Function button for 4 seconds. Your Wireless Headset<sup>BLUCLIP</sup> will beep and the blue LED Indicator will flash 4 times.

### Power OFF

Power OFF by pressing and holding the Multi Function button for 4 seconds. Your Wireless Headset<sup>BLUCLIP</sup> will beep and the blue and red LED Indicator will flash 1 time sequentially.

### Answer a call

Answer a call by quickly pressing the Multi Function button.

### Adjust earphone volume

Adjust earphone volume by pressing the Volume + increase button or the Volume decrease button.

### Re-dial

(phone dependent feature) Re-dial the last number dialed by quickly pressing the Multi Function button.

### Mute/unmute a call

by pressing the Volume + increase or Volume - decrease button for 1 second.

### Reject a call

Reject a call by pressing the Multi Function for 1 second

### End a call

End a call by quickly pressing the Multi Function button.