

KBT130N-1 USER MANUAL

Welcome

Welcome to Bluetooth wireless World. The Bluetooth Speaker phone can be connected wirelessly with your Bluetooth cell phone taken with you. This makes call more free, convenient, flexible and humanized.

* Bluetooth phone is a phone that can support Bluetooth functions.

This Bluetooth Speaker phone is advanced and ingenious, it has the following features:

Conversation can be achieved seamlessly and wirelessly through Bluetooth link.

High quality digital audio interface.

Voice dialing (need Bluetooth cell phone to support voice dialing function).

Built-in DSP echo canceling circuit to cancel echo and reduce noise.

Support Headset V1.1 and Hands free V1.0 profile.

SPECIAL STATEMENT:

Cell phone needs to have the function of Bluetooth audio transmission. Some functions described in this user guide may not be able to operate normally or to be used with some phone models and brands. Read operation instructions for phone carefully. If a phone supports Bluetooth image transmission (such as, NOKIA 7650) only, this kit can't be used with it. This user guide subjects to revision without notice.

1. This device conforms to FCC Part 15.

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: 1) this device may not cause harmful interference, and 2) this device must accept any interference received, including interference that may cause undesired operation.


2. User should not change or modify this device in any ways. The change or modification may be causes cancellation of user's right to use this device and the warranty to user without explicit consent of the party responsible for complying with this regulation.
3. To avoid radio interference to authorized service, this device shall be used in vehicle so as to get maximum protection.
4. This device conforms to Directive R&TTE of May 1995 of European Community and is

CE 678
approved to bear CE label.

5. If no proper protection design or electromagnetic compatibility is considered, almost all devices will be affected by electromagnetic interference (EMI).

Description to control panel

CONTROL PANEL



FUNCTION BUTTON: To perform many correlative functions.

MIC: Including built-in type

Power on/off button: power on/off and hang call

Pairing between Bluetooth kit and Bluetooth phone

* This Bluetooth Speaker phone can only be used after paired with Bluetooth cell phone.

Pairing makes Bluetooth wireless link between Speaker phone and cell phone.

PAIRING BETWEEN BLUETOOTH SPEAKER PHONE AND BLUETOOTH CELL PHONE

INITIAL PAIRING: With Speaker phone powered on and Bluetooth cell phone being close to the kit:

Press function button for from 4 seconds to six seconds, blue indicator flashes per 0.5 second. This indicates that the kit is in headset pairing mode

Press function button for more than 6 seconds or till blue indicator flashes per 1 second. This indicates that the kit is in Speaker phone pairing mode.

Operate cell phone to realize link: **For NOKIA 8910i:**

Enter into function menu → Select Data Link → Select Bluetooth → Select Search for Audio Device → (If correlative Bluetooth device is detected, the name of the correlative Bluetooth device is displayed). Select this device → Enter code 0000

Pairing is completed.

After pairing completed, during Speaker phone linking with Bluetooth phone, the blue indicator is on and red indicator is off.

During pairing, if you click function button, the pairing operation will be cancelled and the kit resumes to standby status.

Connection/Disconnection

CONNECTION

AUTOMATIC CONNECTION:

After initial pairing has been made, the Speaker phone will remember the ID of phone. Every time when you power on the kit, the Speaker phone will automatically search for the Bluetooth cell phone used last time. The blue indicator is off and the red indicator flashes. After wireless link is established, the blue indicator is on and the red indicator is off.

***Note:** When Speaker phone power on, If Bluetooth cell phone is off , even if the phone powers on after the Speaker phone is power on, the bluetooth link is not established also.

MANUAL CONNECTION

When the Speaker phone is in standby mode and isn't connected with Bluetooth cell phone after pairing, you can click function button to make Bluetooth Speaker phone search for paired phone. At this moment, the red indicator flashing and the blue indicator is off. After the connection is established, the blue indicator is on and the red indicator is off.

With Speaker phone in standby mode and not connected with Bluetooth cell phone after pairing, you can operate phone to establish Bluetooth link. Refer to the Bluetooth section of operation instructions for phone for detailed operation method.

***This Speaker phone can store maximum three sets of pairing information.**

CANCEL SEARCHING

You can click the function button to cancel searching and to let the kit resume to standby status during Speaker phone searching for Bluetooth cell phone.

DISCONNECT THE SPEAKER PHONE WITHBLUETOOTH CELL PHONE

With Speaker phone in standby status and connected with cell phone, you can press the function button for more than 6 seconds to disconnect the Speaker phone with Bluetooth cell phone.

If power is turned off, the Speaker phone will automatically be disconnected with Bluetooth cell phone.

MAKE A CALL

Make a call through the keypad of Bluetooth cell phone. During call, the blue and red indicators all light up.

ANSWER A CALL

Ringing for an incoming call, you can click the function button to answer the call, or you can click the power button to reject the call.

HANGUP

During a call, you can click the power button to hang up the call.

CALLSWITCH

1、Switch a call to Phone from Hands free

You can press the Talk button more than 6 seconds or operate the phone menu during a call.

2、Switch a call to Hands free from Phone

First you must found the Bluetooth link, then operate from the phone menu during a call.

ADJUST VOLUME

During Conversation or incoming call, you can click the volume button or press the volume button for a long time to adjust the volume.

Last Number Redial

During the Idle mode, click the '+' button, the system will redial the last number (you have dialed)

This function is only valid for the Bluetooth phone that has voice dialing function.

VOICE TAG

Add voice tag for the number to be voice dialed. Refer to "voice control dialing" section in the user manual for cell phone for operating steps.

INITIATE VOICE DIALING

Standby mode, Bluetooth phone is connected, click the “-” button to initiate voice dialing, a prompt voice can be heard.

User speaks out the voicetag for the number to be dialed. If the spoken voicetag matches a voicetag stored, an outgoing call is given to the number with this voicetag.

During voice dialing, if you want to interrupt this process, you just click the function button.

DESCRIPTION TO THE STATUS OF INDICATORS:

Blue indicator on, red indicator off: indicates that Speaker phone is connected with Bluetooth cell phone.

Blue indicator off, red indicator off: indicates that Speaker phone is power off.

Blue indicator off, red indicator flashing: indicates that Speaker phone is searching for Bluetooth cell phone.

Blue indicator flashing, red indicator off: indicates that Speaker phone is in pairing status.

Blue indicator on, red indicator on: indicates that call is in session.

Description to pairing operation for some common phone brands

Typically there are different operations for cell phones from different manufacturers. (However, there are basically the same operations for different models from the same manufacturer.) The pairing operation for Bluetooth Speaker phone with Motorola, Nokia and Ericsson Bluetooth cell phones are described as follows (See operation instructions for phone for detail operation.):

1 . For Nokia phone (8910i):

Enter into function menu → Select Data Link → Select Bluetooth → Select Search for Audio Device → (If correlative Bluetooth device is detected, the name of the correlative Bluetooth device is displayed). Select this device → Enter pin code

2 . For Motorola phone (V500) :

Enter into MENU Select “Setting” →Select “Connection” →Select “Bluetooth Link” →Select “Hands free” →Select “Scan All” →(If correlative Bluetooth device is detected, the name of the correlative Bluetooth device is displayed). Select this device → Enter pin code .

3 . For Sony Ericsson phone (T68i):

Press middle function key (between dialing key and cancel key) →Select “Connection” →Select “Bluetooth” →Select “Scan device” →(If correlative Bluetooth device is detected, the name of the correlative Bluetooth device is displayed). Select this device → Enter pin code

Phone models supported by this Bluetooth Speaker phone

PHONE MODELS SUPPORTED:

NOKIA : 8910/8910i、6600、6310/6310i、6280、3650

Sony Ericsson : T68/T68i、T610 / T618、P800/P802、P900/P908、T628、Z608、K700

Philips Fisio : 820/826、530

Motorola : A760/A768、V500、V600、E680

Siemens : S55

Panasonic: X88

Attention:

1、Certain functions in this system may not be realized if the mobile phone doesn't support. Please inquire mobile phone manufacturer about the details.

2、This product use battery for power, when battery voltage is lower than normal request, the red led will flash per 3 seconds, this means you must charge the battery with special charger for 3~4 hours, during charging, the red led is high light, once the charge is over then the red led change into shimmer

3、charge one time, talking for about 8 hours OR standby for about 500 hours

If you have any other questions during operation, please contact seller or manufacturer betimes in order to ensure its normal work.

Simple troubleshooting method

	FAILURE	CAUSE ANALYSIS	TROUBLESHOOTING METHOD
1	Can't be switched to hands free mode	No Bluetooth link established.	Conduct pairing operation. Then, establish Bluetooth link using function button or phone menu.
2	Fail to pair.	Phone locks its Bluetooth function.	Re-power up kit and initiate pairing operation again or power phone off then power it on to scan again.
3	Bluetooth link can't be established automatically.	Pairing information in phone or Bluetooth module is cleared.	pairing again.
4	When a call incoming, it is answered in 6 seconds.	Auto answer function is set in phone.	Turn off this function.
5	When a talk Established; however, no voice heard.	Manual switching of voice is needed for some.	Use phone menu to transfer voice to Speaker phone.
6	No voice from phone and Speaker phone.	Bluetooth function of phone is down.	Power phone off then power it on.
7	Broken voice	Too louder	Decrease the volume
8	Pair fail	Pin error	Input paring code:"0000"