

### 3.1 About the Home Screen

### **Setting Locking Function**





The screen will be shown like the right picture after touching Device Unlocked on standby screen. Closing the function can be closed by touch sliding. The PIN number box is displayed after touch sliding if the PIN number is set.

### **Status Window**



Pop-up menu is shown when you touch the status bar on the above screen.
User can see Expansion,
Sync, Sound, Battery and
Alarm on the Pop-up menu.





### 3.1 About the Home Screen



#### **Clock & Alarms**




Set date, time and alarm. The time is automatically set depending on the region setting and also can be controlled arbitrarily.



### 3.1 About the Home Screen

# Messaging





Unread text message and Email can be checked. E-mail is needed to Setup processing that makes email interwork with user's account. It needs an account address and a password. The explanation of the function of text message is on the next page.

#### Tasks



Tasks is the function of managing ongoing work or task.


It supports the efficient work process by prioritizing the tasks.



### 3.1 About the Home Screen



### **Searching the Internet**



Input a word that you want to search for.

Start searching the Internet.


The device is needed to connect to Wireless LAN to search the internet.

The basic searching engine is set to bing engine of Microsoft.



### 3.1 About the Home Screen

### **Getting Started**



'Getting Started'

Quick menu will be shown to set up several basic functions.





You can make a decision whether Getting Stared is shown or not on Hone Screen through Add/remove Getting Started menu.



### 3.2 Title Bar Status Icons

Icons

The network, phone, volume, battery and time of current device is shown as icons on the status bar. The following is explaining the meaning of each icon.

### Title Bar Status Icon Descriptions

Icons	Explanation
9	You have a new notification.
	You have a new text message.
$\boxtimes$	You have a new e-mail message.
8	You have a new instant message.
<b>U</b>	You missed a call.
C.	The speakerphone is on.
	The phone is roaming.
	An alarm is set.
<b>Q</b>	The microphone is on.
<b>(</b> (1)	An internet call is in progress.



### 3.2 Title Bar Status Icons

### Icons

Icons	Explantion
	A bluetooth headset is detected.
<b>②</b>	An ActiveSync connection has been established.
	There was a problem with the ActiveSync synchronization.
<b>⊙</b>	An ActiveSync synchronization is in progress over USB.
3 <b>G</b>	A UMTS network is available.
36	Connecting to a UMTS network.
36	A UMTS connection is active.
3G+	A 3G+ network is available.
E	An EDGE network is available.
<b>∃</b>	Connecting to an EDGE network.
E	An EDGE connection is active.
G	A GPRS network is available.
G C	Connecting to a GPRS network.
6	A GPRS connection is active.
H	An HSDPA network is available.
H	Connecting to an HSDPA network.
HT	An HSDPA connection is active.



### 3.2 Title Bar Status Icons

### Icons

Icons	Explanation
*	Bluetooth is on.
R	Wi-Fi is on but not connected, and no networks are detected.
	Wi-Fi is not connected to a network, and other networks are detected.
$oldsymbol{arphi}$	Other wireless networks are detected.
<u>Q.</u>	Connected to a wireless network.
<b>9</b> ,	Synchronizing through a Wi-Fi connection.
P	Connected to a wireless network, and other networks are detected.
1	Information about a new wireless network is available.
<u>=</u>	A network connection is active.
<b>~</b> ** <b>≥</b>	A network connection is inactive.
M	The phone has maximum signal strength.
Y	The phone has no signal.
$\mathbf{R}$	The phone capability is off.
Y	The phone has no service.
Y.	The phone is searching for service.
ā l	Data is being transferred.
রূ	A voice call is in progress.



### 3.2 Title Bar Status Icons

Icons

Icons	Explanation
<u>(</u>	A voice call in on hold.
<b>*</b>	There is no SIM card present in the computer.
(⊕)	The volume is off and the phone is set to vibrate.
<b>⊀</b> €	The volume is on.
∢×	The volume is off.
<b></b>	The battery has a full charge.
	The battery has a high charge.
Œ	The battery has a medium charge.
	The battery has a low charge.
	The battery has a very low charge.
Œ	The battery is attached to external power and is charging.
<u> </u>	No battery is installed in the computer.
<b>Œ</b>	Call forwarding is on.
00	Voice mail is off.
<b>ॐ</b>	GPS locator is off.
Ф	GPS locator is on.



4.1 To use the phone function

#### **Start the phone function**





When you turn on the PDA, the standby screen is shown like the right picture. After that, you can use the phone function by touching Phone on the left bottom.

### Add the phone number



- 1. Input phone numbers you want to add on the Phone screen.\_\_\_
- 2. Touch in the bottom bar then the phone numbers can be added through Save to contacts menu.
- 3. Save them pressing the OK button after finishing inputting phone number after inputting Family/Sur name through New Contact





### 4.1 To use the phone function

### Designate abbreviated number



You can designate abbreviated numbers using Speed Dial key on Phone Screen.

It is progressing in the way of adding already saved number by Speed Dial.

### Call using abbreviated number



You can make a call using the abbreviated number saved with a phone number. When you press the number longer, the line is connected. If an abbreviated number is saved in double digit, then press second digit longer than fist number.



### 4.2 To use the text message function

#### **Text message**



Text message function can be used by touching Text icon. Received messages can be checked and saved in, replies can be sent and the phone numbers can be saved in the directory.

You can write and send a new message by using New button.




You can write a message on the left screen. Recipient number is on the top.

In the Show menu, you can check sent messages or temporarily saved messages.



Text Messi





### 4.2 To use the text message function

### Text message





When you press the sky blue button once in the Text Messages, you can see the sky blue circle in the center of bottom line. It makes change to the former letter right after texting one letter.



It is the screen when you press the sky blue key twice.

You can see the whole blue circle and that makes you write any letter continually.

#### Text message

#### EX) Enter 7,8,9

The values input in each mode are seen like the right pictures. **Sky-Blue and Red** are operating as the same function.









# 5. Others

### 5.1 Applications

### Windows Media





Window Media supports the function that runs music and video files.

### File Explorer



File manager supports Cut, Copy and Rename etc., like the functions of PC by File Explorer. It also provides Interface similar PC and is available to approach all files and folders inside and outside memory.





## 5. Others


### 5.1 Applications



You can take a picture, shoot a file clip and edit a photo by Pictures & Video. Press 'the image of Camera' first and then press 'Enter' on the hard key pad.

### Task Manager





Task Manager shows current running APP. When an unwanted program or some programs are finished, you can manage the memory efficiently using Task Manager.



# 5. Others

### 5.1 Applications

### **UHF RFID**

PATH: File Explorer->Flash Disk->Rfidhost



Pressing the inventory



Start reading, and the values are indicated.



# **5.** Applications

5.1 Data communication Applications

#### **DATA Communication**



Click WI-FI icon on the bottom right-corner of the screen and touch 'WLAN Insert' like the left picture. Then, PHONE supports phone function and 3G DATA, WI-FI supports the function of on/off WI-FI.

### **Internet Explorer**



You can use Internet through Internet Explorer after connecting WLAN and can see various internet contents like searching and mails

