




## External Photo











## Internal Photo








































**Power Adapter Photo (Model : AF1805-A)**












**Power Adapter Photo (Model : AF1805-B)**







**Power Adapter Photo (Model : AF1805-E)**





