
Users Guide

Digital Technology Two-Way Talkback


Checklist













Step two: The parent unit at least 1 meter from the baby unit, power up the parent unit by loading two rechargeable batteries, press the power button, turn on, the parent unit will link the baby unit automatically and be ready for use.



Cautions

Bundle the power adapter

avoid twist the baby and

cause accident

cord neatly with a twist tie, to





Press and hold 2 seconds to turn on/off

(2) Power light

The light shows green whe the baby unit turns on

(3) Night light

(4) Night light control

(5) Pager

Use to find out parent unit (both parent and baby unit are turning on)

(7) Charging Connector For parent unit charging



4. Red and yellow slow flash and beeping: out

Use to remote control the (from 2 to 6) Indicate the baby unit

volume level

Use to adjust the

Press and hold 2

seconds to turn on/off

night light on baby unit


level of volume

1. Red light bright: turn on

- 2. Slow flash: charging
- 3. Yellow slow flash and beeping: low power

(9) Push to talk Press and hold this

9 • 8







BT05

Baby monitors





A baby unit

(o au



2pcs AAA rechargeable batteries

1PC AC adaptor

Technical Parameters


Model	BT05
Modulation Mode	FHSS
Channel	36 (automatic search)
Baby Unit Power	10dBm
Sensitivity of Parent Unit	-83dBm
AC Adaptor	5V 1A
Battery	DC 1.2V*2AAA
Distanceh	300m (open field)

₩ 55 "Time File"

10° Time Flys*

Method 2:

Charging parent unit with adaptor directly.



Method1:

smoothly.

Put the parent unit above

on baby unit just like the below picture, it is like a

ship sailing which means

everything is going

Other Functions

- ◆ This product uses DECT digital technology to avoid mutual interference with other congeneric products.
- ♦ If the battery level lower than 2.35V, the power light of parent unit flashes in red every 0.5 second. At the same time, parent unit sends "BI" sound every 5 seconds When the battery is at 2.2V, the parent unit will of automatically.
- ◆ Auto mute function, when the parent unit receives a signal from baby unit below a level, we define 50dBM (we think 50dBm is a normal environmental noise), it does no open and keeps silent (no noise).
- ♦ Out of range alarm and range controls, if the Parent uni is out of the range of the Baby unit, after 6 seconds, Parent unit emits a warning tone (BI) every 2. seconds and the power indictor shows in red and yellow alternately.
- ◆ Channel selection automatic.when you turn on the both Parent unit and Baby unit, they will search available channel automatically.

Troubleshooting

Problem	Possible cause	Solution	Usei
Power light does not light	Unit not turn on AC power adapter not connected to the DC jack Batteries low	Press On/Off button Connect AC power adapter to the DC jack Replace batteries	Name
Power light is blinking	Not connect well Batteries low	Make sure the connection OK Replace batteries	Reta
High pitched noise	Units too close to each other Volume set too high	Move parent unit away from baby unit (at least 1 meter / 3 feet) Decrease the volume	Name
No sound on parent unit	Volume off or too low	- Increase the volume	Invoic
No connection between units	Out of range of transmitted signal Units are set to different channels	Move parent unit closer to baby unit Set channel selection switches to the same position on both units.	

BT Series Baby Monitor Maintenance Record

f e	Problem	Possible cause	Solution	User Profile			Repair date	Fault description/failure cause/processing results	Use of spare parts	Completion date	Maintenance center name/mainter personnel signature
f	Power light does not light	 Unit not turn on AC power adapter not connected to the DC 	 Press On/Off button Connect AC power adapter to the DC jack 	Name:	Phone:	_ E-Mail:					
a		jack • Batteries low	Replace batteries	Address:		Post Code:					
e t	Power light is blinking	Not connect well Batteries low	Make sure the connection OK Replace batteries	Retailer Information							
t D	High pitched noise	 Units too close to each other 	Move parent unit away from baby unit (at	Name :		Phone:					
V	• Volume set too night	least 1 meter / 3 feet) Decrease the volume	Address:		Post Code:						
	No sound on parent	■ Volume off or too low	■ Increase the volume	Invoice No:		_ Selling Date:					

美芯[®]TimeFlys[®]





Cautions

- This product is intended as an aid. It is not a substitute for responsible
- Please do not use other power adaptors which may not fit this product
- Please do not expose the baby monitor to extreme cold,heat wet or
- Make sure the baby unit and the adapter cord are always out of reach o the baby at least 1 meter/3 feet away from the baby or crib to avoid a

中国深圳高新区科技中二路软件 园四栋516室

Website: http://www.mcdevices.com

电话: (86) 755-8618-5088 传真: (86) 755-8618-5000 Email: sales@mcdevices.com

Tel:86-755-8618-5088 Fax:86-755-8618-5000 Email: sales@mcdevices.com

Shenzhen, Guangdong, China

ADD: 516 Bld. 4, National Software Park,

2Kejizhong Rd., Shenzhen Hi-Tech, Park,

MCDEVICESCo.Ltd

Website: http://www.mcdevices.com



This device complies with part 15 of the FCC Rules. Operation is subject to the condition that this device does not cause harmful interference (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body: Use only the supplied antenna.

FCC ID:RS5-BT05T