


1. Photographs of Radiated Emissions Test Configuration

Test Mode: Mode 1

FRONT VIEW




REAR VIEW




Test Mode: Mode 2

FRONT VIEW



REAR VIEW



————THE END————