

FCC STATEMENT

Caution: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.



©2013 Blip Toys LLC.
15245 Minnetonka Blvd.
Minnetonka, MN 55345 USA
All Rights Reserved
www.bliptoy.com
MADE IN CHINA
1-800-974-7856
U.S. patent no. 5882241
Products and colors may vary

4+

bottitm
A bot to get crazy

Care Guide

bottibot.com

OUTSIDE

BATTERY INFORMATION:

5 AA


batteries not included

3 AA batteries are used to power the main vehicle. 2 AA batteries are used to power the remote control. These batteries are not included.

- For best performance use only batteries recommended.
- Ensure batteries are inserted using the correct polarity.
- Do not mix new and used batteries
- Do not mix alkaline, standard (carbon-zinc) or rechargeable (nickle-cadmium) batteries.
- Keep packaging for reference since it contains important information.
- Remove exhausted batteries from unit and dispose of in accordance with battery maker's recommendations.
- Do not attempt to recharge non-rechargeable batteries.
- Rechargeable batteries should only be charged under adult supervision.
- Remove rechargeable batteries from the toy before charging.
- The supply terminals are not to be short circuited.
- Remove batteries if the toy will not be used for an extended period of time.
- Use a screwdriver to open the battery compartment door and replace old batteries.

BOTTOM OF BOTTI:


1. ON/OFF Switch. 3. Push lever to open



2. Use a screwdriver to unscrew.

THIS VIEW IS THE UNDER SIDE OF BOTTI.

REMOTE INFORMATION:



INSIDE

