

MP-328 Mp3onChannel Player

Operation Manual

1. Turn on the car power then plug MP3onchannel player into 12V outlet(cigarette lighter) in car. The LED indicator will be blinked(3 seconds each time).
2. Plug any kinds of flash drive into USB connector at the top of MP3onchannel player.
3. Press PLAY button on MP3onchannel player and adjust the car radio channel to match the channel of MP3onchannel.
4. Press one more time on PLAY button to be PAUSE mode.
5. Press NEXT(PREV) button shorter than 1 second, will change to Next/Previous song.
6. You can adjust volume on MP3onchannel player if you press NEXT(PREV) button longer than 2 seconds.
7. Adjust the channel setting if the signal is interfered in your area.
8. When use audio line in player(MP3, CD, DVD.....), you can play music by its operating function.
9. Don't use audio line in player and USB pen drive at the same time.
10. Pull out this unit when not in use.


As USB charger

1. Turn on the car power then plug MP3onchannel player into 12V outlet(cigarette lighter) in car.
2. Any rechargeable Player can be charged by connecting to USB port of this unit.

FCC Statement

You are cautioned that changes or modifications not expressly approved by the part responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

MP-328 Mp3onChannel Player



Channel rotary switch setting list

Rotary sw. Aimed ↓ LED	88.1	88.3	88.5	88.7	88.9
Frequency	88.1MHz	88.3MHz	88.5MHz	88.7MHz	88.9MHz

Made in Taiwan