

ONE YEAR LIMITED WARRANTY

HMDX sells its products with the intent that they are free of defects in manufacture and workmanship for a period of one year from the date of original purchase, except as noted below. HMDX warrants that its products will be free of defects in material and workmanship under normal use and service. This warranty extends only to consumers and does not extend to Retailers.

To obtain warranty service on your HMDX product, contact a Consumer Relations Representative by telephone at 1-800-753-3000 or email cservice@hmdxaudio.com for assistance. Please make sure to have the model number of the product available. Representatives are available 8:30am-7:00pm EST Monday-Friday.

No COD's will be accepted.

1-800-753-3000 8:30 am - 7:00 pm (EST) M - F

HMDX Audio Service Center

e-mail: cservice@hmdxaudio.com HMDX does not authorize anyone, including, but not limited to, Retailers, the subsequent consumer purchaser of the product from a Retailer or remote purchasers, to obligate HMDX in any way beyond the terms set forth herein. This warranty does not cover damage caused by misuse or abuse; accident; the attachment of any unauthorized accessory; alteration to the product; improper installation; unauthorized repairs or modifications; improper use of electrical/power supply; loss of power; dropped product; malfunction or damage of an operating part from failure to provide manufacturer's recommended maintenance; transportation damage; theft; neglect; vandalism; or environmental conditions; loss of use during the period the product is at a repair facility or otherwise awaiting parts or repair: or any other conditions whatsoever that are beyond the control of HMDX.

This warranty is effective only if the product is purchased and operated in the country in which the product is purchased. A product that requires modifications or adoption to enable it to operate in any other country than the country for which it was designed, manufactured, approved and/or authorized, or repair of products damaged by these modifications is not covered under this warranty.

THE WARRANTY PROVIDED HEREIN SHALL BE THE SOLE AND EXCLUSIVE WARRANTY. THERE SHALL BE NO OTHER WARRANTIES EXPRESS OR IMPLIED INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS OR ANY OTHER OBLIGATION ON THE PART OF THE COMPANY WITH RESPECT TO PRODUCTS COVERED BY THIS WARRANTY. HMDX SHALL HAVE NO LIABILITY FOR ANY INCIDENTAL, CONSEQUENTIAL OR SPECIAL DAMAGES. IN NO EVENT SHALL THIS WARRANTY REQUIRE MORE THAN THE REPAIR OR REPLACEMENT OF ANY PART OR PARTS WHICH ARE FOUND TO BE DEFECTIVE WITHIN THE EFFECTIVE PERIOD OF THE WARRANTY.

NO REFUNDS WILL BE GIVEN. IF REPLACEMENT PARTS FOR DEFECTIVE MATERIALS ARE NOT AVAILABLE, HMDX RESERVES THE RIGHT TO MAKE PRODUCT SUBSTITUTIONS IN LIEU OF REPLACEMENT.

This warranty does not extend to the purchase of opened, used, repaired, repackaged and/or resealed products, including but not limited to sale of such products on Internet auction sites and/or sales of such products by surplus or bulk resellers. Any and all warranties or guarantees shall immediately cease and terminate as to any products or

parts thereof which are repaired, replaced, altered, or modified, without the prior express and written consent of HMDX

This warranty provides you with specific legal rights. You may have additional rights which may vary from state to state. Because of individual regulations, some of the above limitations and exclusions may not apply to you. For more information regarding our product line in the USA, please visit: www.hmdxaudio.com

HMDX Jam and HMDX are trademarks of HMDX. ©2013 HMDX. All Rights Reserved. IB-HXB510





Congratulations on your purchase.

Thank you for purchasing the HMDX Jam Zzz Bluetooth® Bedside Sound System for smartphones, tablets, pads, notebook computers and other Bluetooth® enabled devices. Before you begin to Spread the Jam, please take a few moments to read through this manual for an easy explanation of the features and operation of your new Jam Zzz.

Be sure to check out the entire JAM product line on our website www.HMDXaudio.com – Where there's a Jam there's a party!

Jam Zzz Bluetooth® Bedside Sound System Main Features


- Connects wirelessly using proven Bluetooth® technology with smartphones, tablets, pads and many notebooks and MP3 players
- Built-in speaker phone
- Full function dual alarm with snooze and gradual wake
- Digital FM radio
- Superior sound quality
- USB charging port
- 3.5 mm aux in port
- Enhanced LCD display
- Battery backup (Battery type CR-2025 included)

Getting Started

Unpack the unit carefully. Remove all the accessories from the carton. Do not remove any labels or stickers on the bottom of the unit or adapter. Before setting up the unit, verify that the following are present:


- Jam Zzz Bluetooth® Bedside Sound System
- AC power adapter
- 3.5mm audio cable

Jam Zzz Bluetooth® Bedside Sound System Controls and Connections



- Fig.
- 1. Speaker phone selector
- 2. Speaker phone mic
- 3. Power
- 4. Alarm 1
- 5. Source
- 6. Alarm 2
- 7. Play/Pause
- 8. Reverse/Last Track/FM Scan Down
- 9. Forward/Next Track/FM Scan up

- 10. Snooze/Dim/Sleep
- 11. Volume up
- 12. Volume down
- 13. Universal docking cradle
- 14. Time Set
- 15. Aux Line-in Audio Jack
- 16. AC Adapter Input Jack
- 17. USB Charging Port
- 18. FM Antenna



Power Source

This unit is supplied with an AC adapter; take the following steps to connect the adaptor.

- 1. Unwind the power cord of the AC adaptor to its full length.
- 2. Connect the AC adapter to the DC Input (Fig. 2).
- 3. Plug the AC adapter into an outlet (100v 240VAC 50/60 Hz). Connecting this system to any other power source may cause damage to the system. For sufficient ventilation, keep other objects at least 4 inches away from the unit.
- 4. To power the unit off completely, unplug the AC adapter from the wall outlet.

FUNCTIONALITY

Setting Clock Time - Pre-set Clock

This unit is equipped with a pre-set clock, meaning the clock will automatically set itself when first plugged in.

Please note: the clock will automatically default to Eastern Standard Time and will need to be adjusted for other time zones by manually setting the clock.

Setting Clock Time - Manually Setting the Clock

- 1. Set time when unit is plugged in, but ensure the power button has not been activated and is off.
- 2. Press TIME SET button on the back of the unit to begin the Time Setting mode. You will be prompted to select 24 hour or 12 hour display, use the volume buttons on the top of the unit to select the 24/12 hour mode, press TIME SET button again to select the hour using the volume buttons on the top to advance the hour (a PM indicator will display when hour is advanced accordingly), press TIME SET button again to select the minute using the volume buttons on the top to advance.

Setting and Using the Alarms - Setting Alarm 1 or Alarm 2

- 1. Press and hold the desired alarm button (ALARM 1 or ALARM 2) located on the top of the Unit. The hour will begin flashing.
- 2. Use the FORWARD and REVERSE buttons (or the volume up/down buttons) on top of the unit to adjust the hour, paying attention to the AM and PM indicators.
- 3. Press the alarm button again and the minute will begin flashing. Use the FORWARD and REVERSE buttons again to adjust the minute.
- 4. Press the alarm button again to select the source. The JAM Zzz alarm can be set to Beep or FM using the FORWARD and REVERSE buttons. The alarm cannot be set to the Bluetooth® source.
- 5. Press alarm button again to adjust the maximum volume level of the gradual wake feature (alarm begins soft and slowly gets loader) by using the FORWARD and REVERSE buttons to adjust the sound level up or down.

Turning Off the Alarm / Snooze Operation

The JAM Zzz is equipped with gradual wake, which means that the alarm begins soft and slowly gets louder. This will ensure a non-jarring wakeup.

- Press the SNOOZE bar located on the top of the unit and the alarm will sound again in nine minutes.
 - Please note: You may only press the Snooze button during the Alarm mode for one hour (6 times). After the sixth time, the alarm will turn off and will not sound again until the next set time.
- 2. To turn off the alarm, press the (ALARM 1 or ALARM 2) button on the top of the unit.

Listening to your device wirelessly over Bluetooth®

To connect to Bluetooth

- 1. Press the POWER button located on top of the unit.
- Press the Source button on top of unit until "BT" icon image appears on the LCD screen.
- 3. Follow the instructions of your device to pair the unit.
- 4. Pair your device with the unit by selecting JAM Zzz from your Bluetooth® listings on your device or selecting YES. Jam Zzz will sound a hint tone once pairing has occurred.
- 5. Press play on the connected device.

NOTE: You may need to adjust the volume on your audio device to achieve proper volume.

NOTE: When pairing with a computer, please consult your computer manufacturer for Bluetooth pairing instructions and/or the latest Bluetooth Drivers.

Listening to a non-Bluetooth® audio device

- 1. Plug a 3.5mm audio cable (included), into the AUX audio line input located on the back of the unit.
- 2. Plug the other end of the audio cable into the line out or headphone jack of your audio device.
- 3. Press the POWER button located on top of the JAM Zzz.
- 4. Press the SOURCE button on the unit until the AUX icon appears on the display.
- 5. Press play on the connected device.

NOTE: You may need to adjust the volume on your audio device to achieve proper volume.

NOTE: Track forward/reverse and play/pause controls on Jam Zzz will not work when using Line In Audio Jack

Listening to the Radio

Note: For best reception, fully extend the wire antenna. DO NOT strip, alter or attach to other antennas.

- 1. To listen to the radio, press the POWER button located on top of the Unit.
- 2. Press the SOURCE button on the unit until FM and station frequency appears on the display.
- 3. Use the FORWARD and REVERSE buttons on the top of the unit to select desired station. For auto seek press and hold FORWARD or REVERSE for 2 seconds and the tuner will find the next station with the strongest frequency.
- 4. Press the POWER button to turn unit off.

Sleep Feature

While listening to the Bluetooth®, radio or AUX sources, press the SNOOZE / DIM / SLEEP button to activate the sleep feature. This allows you to set a sleep timer for 90, 60, 30, 15 minutes. Once set, the unit will continue playing for the set length of time, then will automatically turn off.

Speaker Phone

If a Bluetooth enabled phone is connected wirelessly to the unit you can receive calls and speak through the microphone on the unit. To answer an incoming call press the ($\cline{\crine{\cline{\cline{\cline{\cline{\cline{\cline{\cline{\cline{\cli$

Note: To place calls you will have to use your phone.

USB Charging Port

This USB port is for charging only. It cannot be used to play music through the unit. In order to use the USB charging feature, you must have the proper cord to connect to your device with a USB Type A connector on the other end.

Volume Control

To adjust the volume use the volume buttons located on the top of the unit.

Display Dimmer Control

Press the SNOOZE / DIM / SLEEP bar to adjust the backlight intensity of clock display. The power needs to be off to use the dimmer control.

6

Backup Battery

This alarm clock is equipped with a battery backup feature (1 CR-2025 battery included and already installed) to keep the clock time and alarm settings during a power outage. The battery is located on the bottom of the unit for easy access.

Maintenance

To Store:

You may leave the unit on display, or you can store it in its packaging in a cool, dry place.

To Clean:

Use only a soft dry cloth to clean the enclosure of the unit. Never use liquids or abrasive cleaner.

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -Reorient or relocate the receiving antenna.
- -Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications to this unit not expressly approved by the part responsible for compliance could void the user's authority to operate the equipment.

IC Note

Note: This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment. Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication.

IMPORTANT SAFEGUARDS:

When using an electrical product, basic precautions should always be followed, including the following:

READ ALL INSTRUCTIONS BEFORE USING

- WARNING: Do not place speakers too close to ears. May cause damage to ear drums, especially in young children.
- Use this product only for its intended use as described in this manual. Do not use attachments not recommended by HMDX.
- HMDX is not liable for any damage caused to iPod/MP3 player or any other device.
- Do not place or store product where it can fall or be dropped into a tub or sink.
- Do not place or drop into water or any other liquid.
- Not for use by children. THIS IS NOT A TOY.
- Never operate this product if it has a damaged cord, plug, cable or housing.
- Keep away from heated surfaces.
- Only set on dry surfaces. Do not place on surface wet from water or cleaning solvents.

Por manual de instrucciones e Información de garantía en español visítenos en www.hmdxaudio.com