

Control circuit board is mainly composed of CPU, power part, control key input, display of LED, remote access, water pump control. By manipulating the buttons can adjust machine ChiKuan mode, timing time; By manipulating the button or remote control can control the machine forward or backward, also can control the machine for automatic cleaning regularly. Machine status can be displayed through the panel of eight LED lights to display (display manual operation, automatic running, ChiKuan, timing, time and other information). Control machine operation, the control of CPU automatically according to the current state and two directional relay control the absorption or release, pumps will start automatically after operation. Automatic cleaning mode, the control automatically according to the current CPU ChiKuan set up according to certain rule and cleaning time.

