




Remove resistor R37 if
installing switch S1

HFE20-1

(257)

C

93
JAN518

