

Hose Handle RF Kit - Wireless Controller – LV11

Installation Instructions

Caution: Disconnect power to central vacuum system before starting

1. Remove low-voltage wires from central vacuum unit, if connected.
2. Install low-voltage wire jumpers (supplied) to the central vacuum unit. Install the other end of the wire jumper to the tabs on the **LV11 Wireless Receiver** labelled “LV”.
3. Mount the LV11 in a suitable location. Ensure the antenna is extended straight up from the top of the unit. **Mount receiver at a minimum distance of 6 feet away from the central vacuum unit in order to prevent electrical interference of the RF signal from the motor.**
4. Insert connector end of the power adapter to the LV11 “9 Vac Input” terminal.
5. Turn power back on to central vacuum unit and plug AC adapter into power source.
6. **To program the Hose Handle Transmitter:** Press, with a pointed object, the switch located on the top side of the **LV11 Wireless Receiver**. Immediately press and hold the right side of the rocker switch located on the Hose Handle for 1 second. Programming is now complete.
7. **Operation of the Transmitter:** to turn on the central vacuum unit, press the right side of the rocker switch located on the Hose Handle. To turn off, press the left side of the rocker switch on the Hose Handle.

Part Nbr: 980 INS-004 Rev 1.1

NOTE: Changes or modifications not expressly approved by Alutron
Modules could void the user's authority to operate the equipment.

April 2005

Hose Handle RF Kit - Wireless Controller – LV11

Installation Instructions

Caution: Disconnect power to central vacuum system before starting

1. Remove low-voltage wires from central vacuum unit, if connected.
2. Install low-voltage wire jumpers (supplied) to the central vacuum unit. Install the other end of the wire jumper to the tabs on the **LV11 Wireless Receiver** labelled “LV”.
3. Mount the LV11 in a suitable location. Ensure the antenna is extended straight up from the top of the unit. **Mount receiver at a minimum distance of 6 feet away from the central vacuum unit in order to prevent electrical interference of the RF signal from the motor.**
4. Insert connector end of the power adapter to the LV11 “9 Vac Input” terminal.
5. Turn power back on to central vacuum unit and plug AC adapter into power source.
6. **To program the Hose Handle Transmitter:** Press, with a pointed object, the switch located on the top side of the **LV11 Wireless Receiver**. Immediately press and hold the right side of the rocker switch located on the Hose Handle for 1 second. Programming is now complete.
7. **Operation of the Transmitter:** to turn on the central vacuum unit, press the right side of the rocker switch located on the Hose Handle. To turn off, press the left side of the rocker switch on the Hose Handle.

Part Nbr: 980 INS-004 Rev 1.1

NOTE: Changes or modifications not expressly approved by Alutron
Modules could void the user's authority to operate the equipment.

April 2005